



SEW
EURODRIVE

Operating Instructions



Frequency Inverters
MOVITRAC® LTE-B+



Contents

1	General information.....	6
1.1	About this documentation	6
1.2	Structure of the safety notes	6
1.2.1	Meaning of signal words	6
1.2.2	Structure of section-related safety notes.....	6
1.2.3	Structure of embedded safety notes	6
1.3	Rights to claim under limited warranty	7
1.4	Exclusion of liability	7
1.5	Copyright notice	7
1.6	Product names and trademarks.....	7
2	Safety notes	8
2.1	Preliminary information	8
2.2	General information	8
2.3	Target group	9
2.4	Designated use	9
2.5	Transportation	10
2.6	Installation/assembly.....	10
2.7	Electrical connection	10
2.8	Protective separation	10
2.9	Startup/operation	11
2.10	Inspection/maintenance	11
3	General specifications	12
3.1	Input voltage ranges	12
3.2	Nameplate.....	12
3.3	Type designation.....	13
3.4	Speed setting range.....	13
3.5	Overload capacity	13
3.6	Protection functions	14
4	Installation.....	15
4.1	General information	15
4.2	Mechanical installation	16
4.2.1	Housing variants and dimensions	16
4.2.2	Mounting position	18
4.2.3	IP20 housing: assembly and installation space	19
4.3	Electrical installation	20
4.3.1	Before installation.....	20
4.3.2	Installation	23
4.3.3	Overview of signal terminals	29
4.3.4	Signal terminal connection example	31
4.3.5	Communication socket RJ45	31
4.3.6	Information Regarding UL	32
4.3.7	Electromagnetic compatibility (EMC)	34
4.3.8	Fieldbus configuration	39

5	Startup	40
5.1	Brief instructions	40
5.2	User interface.....	40
5.2.1	Keypad	40
5.2.2	Parameterization	41
5.2.3	Resetting parameters to default settings.....	42
5.3	Simple startup	42
5.3.1	Terminal mode (factory setting)	42
5.3.2	Keypad mode	43
5.4	Startup in VFC vector control.....	43
5.4.1	Startup of asynchronous motors	43
5.4.2	Startup of synchronous motors	44
5.4.3	Startup of LSPM motors	45
5.5	Startup with PC	45
5.5.1	PC connection	46
5.6	Startup via fieldbus	47
5.6.1	SBus startup.....	47
5.6.2	CANopen startup.....	49
5.6.3	Startup of modbus RTU	54
5.6.4	Description of transferred process data (PD).....	57
5.7	Startup with 87 Hz characteristic curve.....	59
5.8	Additional functions for startup.....	59
5.8.1	Fire mode/emergency mode	59
5.8.2	PI controller mode	59
5.8.3	Master-slave mode.....	61
6	Operation.....	62
6.1	Status of the inverter	62
6.1.1	Display for inhibited inverter	62
6.1.2	Display for enabled inverter	62
6.1.3	Error reset	62
7	Service and error codes.....	63
7.1	Fault memory	63
7.2	Error codes	63
7.3	SEW-EURODRIVE Electronics Service.....	65
7.4	Extended storage.....	65
7.5	Waste disposal.....	66
8	Parameters	67
8.1	Overview of parameters.....	67
8.1.1	Standard parameters	67
8.1.2	Advanced parameters	68
8.2	Advanced parameter description	71
8.2.1	Standard parameters	71
8.2.2	PWM	73
8.2.3	Analog inputs	74
8.2.4	Analog output	77

8.2.5	Speed skip function	78
8.2.6	Adjustment of V/f characteristic.....	79
8.2.7	User relay	80
8.2.8	Inverter behavior in case of enable/restart.....	81
8.2.9	HVAC functions.....	82
8.2.10	Fieldbus settings	85
8.2.11	Display scaling	85
8.2.12	Thermal motor protection to UL508C	86
8.2.13	PI controller	86
8.2.14	Motor control parameter	88
8.3	P-15 Binary input function selection.....	90
8.3.1	Terminal mode	90
8.3.2	Keypad mode	92
8.3.3	SBus, CANopen and slave control mode.....	92
8.3.4	Modbus RTU control mode	93
8.3.5	PI control mode	94
8.4	Parameters for monitoring operating data in real time (read only).....	95
8.4.1	Access to parameter group 0	95
8.4.2	Description of parameter group 0.....	95
9	Technical data.....	98
9.1	Conformity.....	98
9.2	Information on ambient conditions.....	98
9.3	Output power and current carrying capacity without EMC filter	99
9.3.1	1-phase system AC 115 V for 3-phase AC 230 V motors (voltage doubler).....	99
9.3.2	1-phase system AC 230 V for 3-phase AC 230 V motors	100
9.3.3	3-phase system AC 230 V for 3-phase AC 230 V motors	101
9.3.4	3-phase system AC 400 V for 3-phase AC 400 V motors	102
9.4	Output power and current carrying capacity with EMC filter	104
9.4.1	1-phase system AC 230 V for 3-phase AC 230 V motors	104
9.4.2	3-phase system AC 230 V for 3-phase AC 230 V motors	105
9.4.3	3-phase system AC 400 V for 3-phase AC 400 V motors	106
10	Declaration of Conformity.....	108
11	Address list	109
	Index	120

1 General information

1.1 About this documentation

This documentation is an integral part of the product. The documentation is intended for all employees who perform assembly, installation, startup, and service work on the product.

Make sure this documentation is accessible and legible. Ensure that persons responsible for the machinery and its operation as well as persons who work on the device independently have read through the documentation carefully and understood it. If you are unclear about any of the information in this documentation or require further information, contact SEW-EURODRIVE.

1.2 Structure of the safety notes

1.2.1 Meaning of signal words

The following table shows the grading and meaning of the signal words for safety notes.

Signal word	Meaning	Consequences if disregarded
▲ DANGER	Imminent hazard	Severe or fatal injuries.
▲ WARNING	Possible dangerous situation	Severe or fatal injuries.
▲ CAUTION	Possible dangerous situation	Minor injuries
NOTICE	Possible damage to property	Damage to the drive system or its environment.
INFORMATION	Useful information or tip: Simplifies handling of the drive system.	

1.2.2 Structure of section-related safety notes

Section-related safety notes do not apply to a specific action but to several actions pertaining to one subject. The hazard symbols used either indicate a general hazard or a specific hazard.

This is the formal structure of a safety note for a specific section:



SIGNAL WORD

Type and source of hazard.

Possible consequence(s) if disregarded.

- Measure(s) to prevent the hazard.

1.2.3 Structure of embedded safety notes

Embedded safety notes are directly integrated into the instructions just before the description of the dangerous action.

This is the formal structure of an embedded safety note:

- **▲ SIGNAL WORD** Type and source of hazard.
Possible consequence(s) if disregarded.
– Measure(s) to prevent the hazard.

1.3 Rights to claim under limited warranty

A requirement of fault-free operation and fulfillment of any rights to claim under limited warranty is that you adhere to the information in the documentation. Read the documentation before you start working with the product.

1.4 Exclusion of liability

You must comply with the information contained in this documentation to ensure safe operation and to achieve the specified product characteristics and performance features. SEW-EURODRIVE assumes no liability for injury to persons or damage to equipment or property resulting from non-observance of these operating instructions. In such cases, any liability for defects is excluded.

1.5 Copyright notice

© 2016 SEW-EURODRIVE. All rights reserved. Unauthorized reproduction, modification, distribution or any other use of the whole or any part of this documentation is strictly prohibited.

1.6 Product names and trademarks

The brands and product names in this documentation are trademarks or registered trademarks of their respective titleholders.

2 Safety notes

2.1 Preliminary information

The following basic safety notes must be read carefully to prevent injury to persons and damage to property. The user must ensure that the basic safety notes are read and observed. Make sure that persons responsible for the system and its operation, as well as persons who work independently on the unit, have read through the operating instructions carefully and understood them. If you are unclear about any of the information in this documentation, or if you require further information, please contact SEW-EURODRIVE.

Please also observe the supplementary safety notes in the individual chapters of this documentation.

2.2 General information



▲ WARNING

Depending on its enclosure, the unit may have live, uninsulated as well as moving or rotating parts and hot surfaces during operation.

Severe or fatal injuries.

- All work related to transportation, storage, installation, setup/assembly, connection, startup, maintenance and repair may only be carried out by specialists, in strict observance of
 - The relevant detailed documentation
 - The warning and safety signs on the unit
 - All other relevant project planning documents, startup instructions and wiring diagrams
 - The specific regulations and requirements for the system
 - The national/regional regulations governing safety and the prevention of accidents.
- Never install damaged products.
- Submit a complaint to the shipping company immediately in the event of damage.

Unauthorized removal of required covers, improper use, or incorrect installation and operation may result in severe injury to persons, or damage to machinery.

Refer to the following chapters for more information.

2.3 Target group

Mechanical work of any kind may be carried out only by trained specialists. Specialists in the context of this documentation are persons who are familiar with the design, mechanical installation, troubleshooting and maintenance of the product and have the following qualifications:

- Training in mechanical engineering (for example, as a machinist or mechatronics technician) and the successful completion of final examinations.
- Knowledge of this documentation.

Electrical work of any kind may be carried out only by skilled persons. In the context of this documentation, skilled persons are persons who are familiar with the electrical installation, startup, troubleshooting and maintenance of the product and who have the following qualifications:

- Training in electrical engineering, e.g. as an electrician or mechatronics technician (final examinations must have been passed).
- Knowledge of this documentation.

In addition to that, they must be familiar with the relevant safety regulations and laws, especially with the requirements of the performance levels according to DIN EN ISO 13849-1 and all other standards, directives and laws specified in this documentation. The above-mentioned persons must have the express authorization of the company to operate, program, parameterize, identify and ground units, systems and circuits in accordance with safety technology standards.

All work in the areas of transportation, storage, operation and waste disposal must be performed by suitably trained personnel.

2.4 Designated use

Frequency inverters are components for controlling asynchronous AC motors. Frequency inverters are components intended for installation in electrical systems or machines. Never connect capacitive loads. Operation with capacitive loads results in over voltages and may destroy the unit.

The following standards apply, if the frequency inverters are marketed in the EU/EFTA:

- In case of installation in machines, startup of the inverters (meaning the start of designated use) is prohibited until it is determined that the machine meets the requirements stipulated in Directive 2006/42/EC (Machinery Directive); observe EN 60204.
- Startup (i.e. the start of designated use) is only permitted under observance of the EMC Directive (2014/30/EU).
- The frequency inverters comply with the requirements of the Low Voltage Directive 2014/35/EU. The harmonized standards of the EN 61800-5-1/DIN VDE T105 series in connection with EN 60439-1/VDE 0660 part 500 and EN 60146/VDE 0558 are applied to these frequency inverters.

Observe the technical data and the connection requirements specified on the nameplate and the operating instructions.

2.5 Transportation

Inspect the shipment for transport damage as soon as you receive the delivery. Inform the shipping company immediately of any damage. If necessary, put startup on hold.

Note the following points regarding transport:

- Before transportation, cover the connections with the supplied protection caps.
- Place the unit only on the cooling fins or on a side without connectors during transportation.
- Ensure that the unit is not subjected to mechanical impact during transportation.

If necessary, use suitable, sufficiently rated handling equipment. Prior to startup, remove the transport protection.

Observe the information on climatic conditions as stated in chapter "Technical Data".

2.6 Installation/assembly

Ensure that the unit is installed and cooled according to the regulations in the related documentation.

Protect the unit from excessive strain. Especially during transportation and handling, do not allow the components to be deformed or insulation spaces altered. Electrical components must not be mechanically impaired or irreparably damaged.

The following applications are prohibited unless explicitly permitted:

- Use in potentially explosive atmospheres,
- Use in areas exposed to harmful oils, acids, gases, vapors, dust, radiation, etc.
- Use in applications that are subject to mechanical vibration and shock loads in excess of the requirements in EN 61800-5-1.

Observe the notes in the "Mechanical Installation" chapter.

2.7 Electrical connection

Observe the applicable national accident prevention regulations when working on a live drive controller.

Perform electrical installation according to the pertinent regulations (e.g. cable cross sections, fusing, protective conductor connection). The documentation contains additional notes.

Make sure that preventive measures and protection devices comply with the applicable regulations (e.g. EN 60204-1 or EN 61800-5-1).

Required preventive measures:

Type of energy transfer	Preventive measure
Direct power supply	<ul style="list-style-type: none"> • Ground connection

2.8 Protective separation

The unit meets all requirements for protective separation of power and electronics connections in accordance with EN 61800-5-1. To ensure protective separation, all connected circuits must also meet the requirements for protective separation.

2.9 Startup/operation



▲ CAUTION

The surfaces of the unit and any connected components, e.g. braking resistors, can reach high temperatures during operation.

Danger of burns.

- Let the unit and external options cool down before you start working on them.

Do not deactivate the monitoring and protection devices, even during the test run.

When in doubt, switch off the unit whenever changes occur compared with normal operation (e.g. increased temperatures, noise, oscillation). Determine the cause of the fault and, if necessary, contact SEW-EURODRIVE.

Where required, systems in which such units are installed must be equipped with additional monitoring and protection devices in accordance with the respective applicable safety regulations, e.g. the law governing technical equipment, accident prevention regulations, etc.

Additional preventive measures may be necessary for applications with increased hazard potential. You must check the functionality of protection devices each time you change the configuration.

Connections that are not being used must be covered with the supplied protection caps during operation.

Do not touch live components or power connections immediately after disconnecting the unit from the voltage supply because some capacitors may still be charged. Adhere to a minimum switch-off time of 10 minutes. Observe the corresponding labels on the unit.

When the unit is switched on, dangerous voltages are present at all power connections as well as at connected cables and motor terminals. This applies even when the unit is not running and the motor is at standstill.

The fact that the operation LED and other display elements are no longer illuminated does not indicate that the unit has been disconnected from the supply system.

Mechanical blocking or internal safety functions within the unit can cause the motor to stop. Eliminating the cause of the problem or performing a reset may help to restart the drive automatically. If, for safety reasons, this is not permitted for the drive-controlled machine, disconnect the unit from the supply system before you start troubleshooting.

2.10 Inspection/maintenance



▲ WARNING

Danger of electric shock due to exposed, live parts in the unit.

Severe or fatal injuries.

- Never open the unit.
- Only SEW-EURODRIVE is authorized to carry out repairs.

3 General specifications

3.1 Input voltage ranges

Depending on the model and the nominal power, the frequency inverters are designed for direct connection to the following voltage sources:

MOVITRAC® LTE-B			
Nominal voltage	Size	Connection type	Rated frequency
110 – 115 V ± 10%	1, 2	1-phase	50 – 60 Hz ± 5%
200 – 240 V ± 10%	1, 2 and 3	1-phase* / 3-phase	50 – 60 Hz ± 5%
380 – 480 V ± 10%	1, 2 and 3 s	3-phase	50 – 60 Hz ± 5%

Units that are connected to a 3-phase supply system are designed for a maximum power grid imbalance of 3% between the phases. For supply systems with a power grid imbalance of more than 3% (for example, in India and parts of the Asia-Pacific region including China), SEW-EURODRIVE recommends that you use input chokes.


INFORMATION



*Single-phase frequency inverters can also be connected to 2phases of a 3-phase power supply system of 200 – 240 V.

3.2 Nameplate

The following figure shows a nameplate.



9007212734288395

3.3 Type designation

Example: MCLTE-1-B 0015-201-1-00		
Product name	MCLTE	MOVITRAC® LTE-B
Version	B	Version status of the unit series
Motor	1	Only single-phase motors
Recommended motor power	0015	0015 = 1.5 kW
Supply voltage	2	<ul style="list-style-type: none"> 1 = 115 V 2 = 200 – 240 V 5 = 380 – 480 V
Interference suppression on the input	0	<ul style="list-style-type: none"> 0 = Class 0 A = Class A B = Class B
Connection type	1	<ul style="list-style-type: none"> 1 = 1-phase 3 = 3-phase
Quadrants	1	1 = 1-quadrant operation without brake chopper 4 = 4-quadrant operation with brake chopper
Design	00	<ul style="list-style-type: none"> 00 = Standard IP20 housing 10 = IP55/NEMA-12K housing without switch 20 = IP55/NEMA-12K housing with switch 30 = IP66/NEMA-4X housing without switch 40 = IP66/NEMA-4X housing with switch
Country-specific variant	(60 Hz)	60 Hz = 60 Hz design

3.4 Speed setting range

Control mode	Speed setting range
V/f	1:10
IM Vector	1:20
PM Vector	1:10

3.5 Overload capacity

All MOVITRAC® LTE-B products have the following overload capacity:

- 150% for 60 seconds
- 175% for 2 seconds

With an output frequency of < 10 Hz, the overload capacity is reduced to 150% for 7.5 seconds.

3.6 Protection functions


- Short circuit output, phase-phase, phase-ground
- Output overcurrent
- Overload protection
- Overvoltage shutdown
- Undervoltage shutdown
- Shutdown caused by overtemperature
- Shutdown caused by undertemperature

4 Installation

The next chapter describes the installation.

4.1 General information

- Carefully check the frequency inverter for damage before installation.
 - Store the frequency inverter in its original packaging until it is used. The storage location must be clean and dry with an ambient temperature between $-40\text{ }^{\circ}\text{C}$ and $+60\text{ }^{\circ}\text{C}$.
 - Install frequency inverter in a suitable housing on a level, vertical, non-flammable, and vibration-free surface. If a certain IP degree of protection is required, observe EN 60529.
 - Keep flammable materials away from the frequency inverter.
 - Prevent the ingress of conductive or flammable foreign objects.
 - The relative humidity must be kept below 95 % (condensation is not permitted).
 - Protect the IP66 frequency inverter from direct sunlight. Use a cover when using the inverter outdoors.
 - Frequency inverters can be installed next to each other. Ensure sufficient ventilation space between the individual devices. If the frequency inverter is to be installed above another frequency inverter or another device that dissipates heat, then there must be a vertical minimum clearance of 150 mm. To enable self-cooling, the control cabinet must either be cooled through forced ventilation, or dimensioned accordingly. See chapter "IP20 housing: Installation and installation space" (\rightarrow 19).
 - The maximum permitted ambient temperature during operation is $+50\text{ }^{\circ}\text{C}$ for IP20 frequency inverters, and $+40\text{ }^{\circ}\text{C}$ for IP55 and IP66 frequency inverters. The minimum permitted ambient temperature during operation is $-10\text{ }^{\circ}\text{C}$.
- Note the special degrees of protection in section "Information on ambient conditions" (\rightarrow 98).
- A device for installing DIN support rails is only available for size 1 and 2.
 - Install the frequency inverter only as depicted in the following figure:



9007206567363979

4.2 Mechanical installation

4.2.1 Housing variants and dimensions

Housing variants


MOVITRAC® LTE-B+ is available with 3 housing variants:

- IP66/NEMA 4X
- IP55/NEMA 12K
- IP20 housing for installation in control cabinets

IP55/NEMA-12K and IP66/NEMA-4X housings are protected against humidity and dust. These frequency inverters can be operated indoors in a dusty or damp environment. The electronics of the IP66 frequency inverter are identical to frequency inverters in IP20 design. The only difference is in the housing dimensions and the weight.

In degree of protection IP66, the frequency inverters are also available with switch options, such as main switch, direction of rotation switch, and potentiometer.

Dimensions of IP66/NEMA-4X housings (LTE xxx -30 and -40)



9007205178204043

22511067/EN – 04/2016

Dimension table

Dimensions		Size 1	Size 2	Size 3
Height (A)	mm	232	257	310
Width (B)	mm	161	188	210.5
Depth (C)	mm	179	186.5	252
Weight	kg	2.8	4.6	7.4
a	mm	148.5	176	197.5
b	mm	6.25	6	6.5
c	mm	25	28.5	33.4
d	mm	189	200	251.5
Tightening torque for power terminals	Nm	1	1	1
Tightening torque for control terminals	Nm	0.5	0.5	0.5
Recommended screw size		4 × M4	4 × M4	4 × M4

IP66 cable openings

Use suitable cable glands to achieve the corresponding IP/NEMA classification.


The required cable bushings can be broken out with suitable tools.

Dimensions		Size 1	Size 2	Size 3
X	mm	22	28.2	28.2
	PG/M ¹⁾	PG13.5/M20	PG21/M25	PG21/M25
Y ²⁾	mm	22	22	22
	PG/M ¹⁾	PG13.5/M20	PG13.5/M20	PG13.5/M20
Z ²⁾	mm	22	22	22
	PG/M ¹⁾	PG13.5/M20	PG13.5/M20	PG13.5/M20

1) The data above refers to plastic screws.

2) Cable bushings Y and Z are pre-punched

Dimensions of the IP20 housing



Dimensions	Unit	Size 1	Size 2	Size 3
Height (A)	mm	174	220	261
Width (B)	mm	82	109	131
Depth (C)	mm	122.6	150	178
Weight	kg	1.1	2	4.5
a	mm	50	63	80
b	mm	162	209.0	247
c	mm	16	23	25.5
d	mm	5	5.25	7.25
Tightening torques for power terminals	Nm	1	1	1
Tightening torques for control terminals	Nm	0.5	0.5	0.5
Recommended screws		4 × M4	4 × M4	4 × M4

4.2.2 Mounting position


The frequency inverter may only be installed vertically.

4.2.3 IP20 housing: assembly and installation space

For applications that require a higher IP degree of protection than IP20, the frequency inverter must be installed in a control cabinet. Observe the following requirements:

- The control cabinet must be made of a heat conductive material unless it has forced air cooling.
- When using a control cabinet with ventilation openings, the openings must be provided above and below the frequency inverter to allow for unobstructed circulation of air. The air must be supplied below the frequency inverter and dissipated above it.
- If the frequency inverter is operated in external environments with particles of dirt (such as dust), ventilation openings either have to be equipped with a suitable particle filter or forced air cooling has to be used. The filter has to be serviced and cleaned.
- In environments with a high level of humidity, salt or chemicals, a suitable enclosed control cabinet (without ventilation openings) must be used.
- The IP20 frequency inverter can be assembled directly next to one another without clearance.

Minimum clear-
ances during in-
stallation



11938462859

Size	X	Y	Z	Air flow rate
	mm	mm	mm	m³/h
1	50	50	33	11
2	75	50	47	11
3	100	50	52	26

4.3 Electrical installation

Adhere to the safety instructions in chapter 2 during installation.



▲ WARNING

Electric shock due to charged capacitors. Dangerous voltage levels may still be present inside the unit and at the terminals up to ten minutes after disconnection from the power supply.

Severe or fatal injuries.

- Wait ten minutes after disconnecting the frequency inverter from the power supply as well as disconnecting the line voltage and the DC 24 V voltage. Then, establish that the unit has been de-energized. Only then, start to work on the unit.
- The frequency inverter may only be installed by electrical specialists in compliance with the relevant directives and regulations.
- The grounding cable must be designed for the maximum fault current of the voltage source that is usually limited by fuses or motor protection switches.
- The frequency inverter has the degree of protection IP20. If higher degrees of protection are required, use a suitable housing or the IP55/NEMA-12K or IP66/NEMA-4X version.
- Make sure the frequency inverters are properly grounded. See wiring diagram in section Connecting inverter and motor.

4.3.1 Before installation

- Make sure that supply voltage, frequency, and number of phases (single- or three-phase) correspond with the nominal values of the frequency inverter on delivery.
- A disconnecting switch or similar disconnecting element must be installed between voltage supply and frequency inverter.
- Never connect the power supply to the output terminals U, V or W of the frequency inverter.
- Do not install automatic contactors between frequency inverter and motor. Adhere to a minimum clearance of 100 mm at points where control cables and electric power lines are installed close to each other, and an angle of 90° for crossing cables.
- The cables are only protected by slow-blow high-power fuses or motor circuit breaker. You find more information in section "Permitted voltage supply systems" (→ 23).
- Make sure that shielding and sheaths of power cables are designed according to the wiring diagram in section "Connecting frequency inverter and motor" (→ 26).
- Make sure that all terminals have been tightened with the proper tightening torques.
 - Control terminals: 0.5 Nm
 - Power terminals: 1 Nm

Line contactors

Use only line contactors in utilization category AC-3 (EN 60947-4-1).

Make sure to observe a minimum time interval of 120 seconds between two cycles.

Line fuses

Fuse types:

- Line protection types in utilization categories gL, gG:
 - Nominal fuse voltage \geq nominal line voltage
 - The nominal fuse current must be designed for 100% of the nominal frequency inverter current, depending on the use of the frequency inverter.
- Miniature circuit breaker with characteristic B:
 - Nominal circuit breaker voltage \geq nominal line voltage
 - The nominal currents of the miniature circuit breakers must be 10% higher than the nominal frequency inverter current.

Residual current device



▲ WARNING

No protection against electric shock if an incorrect type of residual current device is used.

Severe or fatal injuries.

- Use only universal current sensitive residual current devices of type B for 3-phase frequency inverters.
-
- A 3-phase frequency inverter creates a DC component in the leakage current and may greatly reduce the sensitivity of a type-A residual current device. A type-A residual current device is therefore not permitted as a protection device.
Use only a type-B residual current device.
 - If the use of a residual current device is not stipulated in the standards, SEW-EURODRIVE recommends not using a residual current device.

Operation on IT system

Only IP20 units can be operated at the IT system. To operate a MOVITRAC® LTE-B+ on the IT system, the integrated EMC filter must be deactivated. To do so, screw out the EMC screw on the side of the device.


⚠ WARNING



Danger of electric shock. Dangerous voltage levels may still be present inside the unit and at the terminals up to 10 minutes after disconnection from the power supply.


Severe or fatal injuries.

- Disconnect the frequency inverter from the power supply at least 10 minutes before you screw out the EMC screw.



17511197323

[1] EMC screw



17511225099

SEW-EURODRIVE recommends using earth-leakage monitors with pulse code measurement in voltage supply systems with a non-grounded star point (IT systems). The use of such devices prevents the earth-leakage monitor mis-tripping due to the earth capacitance of the frequency inverter.

Operation on TN system with FI switch (IP20)

IP20 frequency inverters with integrated EMC filter (e.g., MOVITRAC® LT xxxx xAx-x-00 or MOVITRAC® LT xxxx xBx-x-00) have a higher leakage current than units without an EMC filter. The EMC filter can trigger faults when operated with residual current devices. Deactivate the EMC filter to reduce the leakage current. To do so, remove the EMC screw on the side of the unit. See figure in chapter "Operation on IT systems".

4.3.2 Installation

Connect the frequency inverter as shown in the wiring diagrams below. Ensure proper wiring in the motor terminal box. A distinction is made between the following two basic connections: star connection and delta connection. Make sure that the motor is connected with the voltage source in such a way that it is supplied with the correct operating voltage.

You find more information in the figure in section "Connection in the motor terminal box" (→ 25).

It is recommended that you use a 4-core PVC-insulated and shielded cable as the power cable. Route this cable in accordance with the relevant national regulations of the industry sector as well as the rules and standards. Conductor end sleeves are required in order to connect the power cables to the frequency inverter.

The power connections of frequency inverters in size 3 must be designed with crimp ring cable lugs to ensure safe contact.

The grounding terminal of each frequency inverter must be connected individually and **directly** to the ground busbar (mass) of the installation site (via a filter, if available).

See section "Connecting frequency inverter and motor" (→ 26).

Do not loop the ground connections of the MOVITRAC® LT inverter from one inverter to the other. Furthermore, do not route the ground connections to the inverters from other inverters.

The impedance of the ground circuit must comply with the local safety regulations of the industry sector.

To comply with UL regulations, all earth connections must be designed with UL-listed crimping ring cable lugs.

Permitted voltage supply systems

- **Voltage supply systems with grounded star point**

The frequency inverter is intended for operation on TN and TT systems with directly grounded star point.

- **Voltage supply systems with non-grounded star point**

Operation on voltage supply systems with non-grounded star point (for example IT systems) is only permitted for frequency inverters with degree of protection IP20.


- **Voltage systems with grounded outer conductor**

On voltage supply systems, the frequency inverters may only be operated with a maximum phase-to-ground AC voltage of 300 V.

Opening the front cover

IP66 for all sizes

Remove the 2 screws on the inverter front to open the front cover.



[1] Screws of the front cover

Connecting a braking resistor

- Shorten the cables to the required length.
- Use 2 tightly twisted leads or a 2-core shielded power cable. The cross section corresponds to the rated current of the inverter.
- Secure the bimetallic relays against overload with trip characteristics of trip class 10 or 10 A, in accordance with EN 60947-4-1. Set the tripping current to the value I_F . Do not use electronic or electromagnetic fuses because these can be triggered even in case of short-term excess currents that are still within the tolerance range.
- For braking resistors in the BW...-...T series, you can connect the integrated thermostat using a 2-core, shielded cable as an alternative to a bimetallic relay.
- The flat-type braking resistors have internal thermal overload protection (fuse cannot be replaced). Install the flat-design braking resistors together with the appropriate touch guard.

⚠ WARNING




Dangerous voltage levels can still be present inside the unit and at the terminals up to 10 minutes after disconnection from the power supply.

Severe or fatal injuries.

- Disconnect and insulate the frequency inverter from the power supply for at least 10 minutes before removing the braking resistance.
- Brake out the touch protection installed at the factory.


The following figure shows the wiring diagram for the braking resistor.




Connection in the motor terminal box

Connection types for motors: star, delta, double star, or star according to NEMA. The nameplate of the motor indicates the nominal voltage for the connection type that has to match the operating voltage of the frequency inverter.

R13




Low voltage Δ




High voltage Δ


R76




Low voltage Δ



High voltage Δ

DR/DT/DV

Low voltage ㄥ



High voltage ㄥ

Connecting frequency inverter and motor**▲ WARNING**

Danger of electric shock. Incorrect wiring can lead to dangerously high voltages. Severe or fatal injuries.

- Adhere to the connection sequence depicted below.

In the following applications, always cut-off the brake in the AC and DC circuits:


- All lifting applications.
- Applications that require a quick brake reaction time.

INFORMATION

In case of a new device, the terminal slots DC+ and BR have a cover installed that can be broken out if required.

Connect the brake rectifier using a separate supply system lead.

Supply via the motor voltage is not permitted!



18014401442886667

- * Only sizes 2 and 3
- [1] Power supply contactor at the frequency inverter
- [2] Power supply at the brake rectifier, switched via K10
- [3] Control contactor/relay for supplying the brake rectifier with current. Control via relay contact [4] in the frequency inverter.
- [4] Isolated relay contacts
Set in parameter *P-18* = 0
- V+ External current supply AC 250 V/DC 30 V at max. 5 A
- V_{DC} BMV DC voltage supply BMV
- V_{AC} BMK AC voltage supply BMK

22511067/EN – 04/2016

Motor temperature protection (TF/TH)

Motors with an internal temperature sensor (TF, TH or similar) can be connected directly to the frequency inverter.

If the thermal protection is triggered, the frequency inverter displays the error "E-triP".

The sensor is connected to terminal 1 (+24 V) and terminal 4 (digital input DI3 / analog input AI2) see section Overview of signal terminals. To receive overtemperature shutdown, the following must additionally be set at the parameters:

Parameter	Setting
P-15	Select the program that contains the TF/TH evaluation on DI3 (e.g. <i>P-15 = 3</i>)
P-48	PTC-th

The shutdown level is set to 2.5 kΩ.

Multi-motor drive/group drive

The total of the motor currents must not exceed the nominal current of the frequency inverter. The maximum permitted cable length for the group is limited to the values of single connection. See chapter "Technical data" (→ 98).

The motor group is limited to five motors and must not differ by more than 3 frame sizes.

Multi-motor operation is only possible with AC asynchronous motors, not with synchronous motors.

SEW-EURODRIVE recommends to use an output choke "HD LT xxx", additionally unshielded cables, and a maximum permitted output frequency of 4 kHz for groups of more than 3 motors.

4.3.3 Overview of signal terminals




⚠ CAUTION


Applying voltages of more than 30 V to the signal terminals can damage the controller.

Possible damage to property.

- The voltage applied to the signal terminals must not exceed 30 V.



IP20 and IP55



IP55 and IP66 with switch option

The signal terminal block is equipped with the following signal terminals:

Ter- minal no.	Signal	Connection	Description
1	+24 V ref out	Output +24 V: Reference voltage	Reference voltage for activating DI1 – DI3 (max. 100 mA)
2	DI 1	Digital input 1	Positive logic
3	DI 2	Digital input 2	"Logic 1" input voltage range: DC 8 – 30 V "Logic 0" input voltage range: DC 0 – 2 V
4	AI/DI	Analog input 2 (12 bit) Digital input 3	0 – 10 V, 0 – 20 mA, 4 – 20 mA "Logic 1" input voltage range: DC 8 – 30 V
5	+10 V	Output +10 V: Reference voltage	10 V reference voltage for analog input (Pot. supply +, 10 mA max., 1 k Ω min.)
6	AI/DI	Analog input 1 (12 bit) Digital input 4	0 – 10 V, 0 – 20 mA, 4 – 20 mA "Logic 1" input voltage range: DC 8 – 30 V
7	0 V	0 V: Reference potential	0 V: Reference potential for analog input (potential shift)
8	AO/DO	Analog output (10 bits) Digital output	0 – 10 V, max. 20 mA analog 0/24 V, max. 20 mA digital
9	0 V	0 V: Reference potential	0 V: Reference potential for analog output
10	Relay switch- ing voltage	Input relay switching voltage	NO contact (AC 250 V / DC 30 V at 5 A)
11	Relay contact	Relay contact	

If 0 V is present at terminal 7 or 9, all digital inputs and multi-functional inputs (binary operated) are compatible with the PLC requirement of IEC 61131.

The following switching threshold applies to all digital inputs and multi-functional inputs (binary operated):

Logic "1" input voltage range: 8 – 30 V


Logic "0" input voltage range: 0 – 4 V

INFORMATION



Terminals 7 and 9 can be used as GND reference potential if the frequency inverter is controlled via PLC.

4.3.4 Signal terminal connection example




15845578507

- [1] Motor temperature sensor TF/TH
- [2] Analog velocity control/potentiometer
- [3] Control contactor/relay for supplying the brake rectifier with current

4.3.5 Communication socket RJ45

Socket at unit



13515899787

- [1] SBus-/CAN bus-
- [2] SBus+/CAN bus+
- [3] 0 V
- [4] RS485- (engineering)
- [5] RS485+ (engineering)
- [6] +24 V (output voltage)
- [7] RS485- (Modbus RTU)
- [8] RS485+ (Modbus RTU)

4.3.6 Information Regarding UL



INFORMATION

Due to UL requirements, the following chapter is always printed in English independent of the language of the documentation.

Ambient Temperature

The units are suitable for an ambient temperature of 40 °C, max. 60 °C with derated output current.

To determine output current rating at higher than 40 °C, the output current should be derated 2.5 % per °C between 40 °C and 50 °C, and 3 % per °C between 50 °C and 60 °C.

Field Wiring Power Terminals

- Use 60/75 °C copper wire only – Models with suffix 0003 to 0300.
Use 75 °C copper wire only – Models with suffix 0370 to 0750.
- Tighten terminals to in-lbs (Nm) as follows:

Series	Frame Size	in-lbs	Nm
MOVITRAC®	0XS, 0S, 0L	4	0.5
	1, 2S	5	0.6
	2	13	1.5
	3	31	3.5
	4, 5	120	14

Short Circuit Current Rating

- Suitable for use on a circuit capable of delivering not more than 200,000 rms symmetrical amperes:
 - MOVITRAC® models with suffix 0003 to 0750 (400 V units only).
Max. voltage is limited to 500 V.
 - MOVITRAC® models with suffix 0003 to 0300 (230 V units only).
Max. voltage is limited to 240 V.

Branch Circuit Protection

Series		Models	max. Fuse Rating
230 V, 1-phase	MOVITRAC®	0003/0004/0005/0008	15 A / 250 V
		0011/0015/0022	30 A / 250 V
230 V, 3-phase	MOVITRAC®	0003/0004/0005/0008	15 A / 250 V
		0011/0015/0022	20 A / 250 V
		0037	30 A / 250 V
		0055/0075	110 A / 250 V
		0110	175 A / 250 V
		0150	225 A / 250 V
		0220/0300	350 A / 250 V
400 V, 3-phase	MOVITRAC®	0003/0004/0005/0008/0011/0015	15 A / 600 V
		0022/0030/0040	20 A / 600 V
		0055/0075	60 A / 600 V
		0110	110 A / 600 V
		0150/0220	175 A / 600 V
		0300	225 A / 600 V
		0370/0450	350 A / 600 V
		0550/0750	500 A / 600 V

Motor Overload Protection

The units are provided with motor overload protection with a trip current adjusted to 150 % of the rated motor current.

4.3.7 Electromagnetic compatibility (EMC)

Frequency inverters with an EMC filter are designed for use in machines and drive systems. They meet the EMC product standard EN 61800-3 for drives with variable speed. For an EMC-compliant installation of the drive system, observe the specifications of Directive 2004/108/EC (EMC) of the European Council.

Interference immunity

With regard to interference immunity, the frequency inverter with an EMC filter meets the limit values defined in the standard EN 61800-3 and can therefore be used for both industrial and domestic (light industrial) applications.

Interference emission

With regard to interference emission, the frequency inverter meets the EMC limit values of the standards EN 61800-3 and EN 55014. The frequency inverter is suitable for industrial as well as household applications (light industry).

Install the frequency inverter as specified in chapter "Installation" (→ 15) to ensure best possible electromagnetic compatibility. Ensure proper ground connections for the frequency inverter. Use shielded motor cables to comply with the specifications on interference emission.

The conditions for use in drive applications are defined in the following tables.

Inverter type with filter	Cat. C1 (class B)	Cat. C2 (class A)	Cat. C3
230 V, 1-phase LTE-B xxxx 2B1-x-xx	No additional filtering required. Use a shielded motor cable.		
230 V/400 V, 3-phase LTE-B xxxx 2A3-x-xx LTE-B xxxx 5A3-x-xx	Use an external filter of the type NF LT 5B3 0xx. Use a shielded motor cable.	No additional filtering required.	


Use an external filter and a shielded motor cable to comply with the specifications on frequency inverters without internal filter.

Inverter type without filter	Cat. C1 (class B)	Cat. C2 (class A)	Cat. C3
230 V, 1-phase LTE-B xxxx 201-x-xx	Use an external filter of the type NF LT 2B1 0xx. Use a shielded motor cable.		
230 V, 3-phase LTE-B xxxx 203-x-xx 400 V, 3-phase LTE-B xxxx 503-x-xx	Use an external filter of the type NF LT 5B3 0xx. Use a shielded motor cable.		

General specifications for connection of the motor shield

For all applications with a expectedly higher EMC load, using shielded cables is recommended. The shield must be connected as follows:


Connect the shield by the shortest possible route and make sure it is grounded over a wide area at both ends. This also applies to cables with several shielded core strands.



9007200661451659

Recommendation for connecting the motor shield with an IP20 frequency inverter

Sizes 2 and 3



17304181003

- | | |
|------------------------------|------------------------------|
| [1] Motor cable | [4] Communication cable RJ45 |
| [2] Additional PE connection | [5] Control cables |
| [3] Encoder cable | |


The shield plate can be used optionally for size 2 and 3 of the IP20 design. Proceed as follows to adjust:

1. Loosen the 4 screws on the slotted holes.
2. Move the plate up to the stop according to the required size.
3. Tighten the screws again.

Make sure that the plate is correctly attached to the PE connection.

Recommendation for motor shield connection at frequency inverters with IP66

Install the additional internal shield plate (included in the delivery of each LTE-B-IP66) at the designated position of the inverter.




17304186379

- [1] Shield plate
- [2] Retaining screws
- [3] Cable gland seals

The use of metal screw fittings is recommended to connect the motor shield to the device. For size 2, the threads must be at least 8 mm.

Cable gland installation (example: Size 2)




17304190731

- [1] Shield plate
- [2] Retaining screws
- [3] Cable gland seals

4.3.8 Fieldbus configuration

This topology applies to the installation of the frequency inverters at an SBus gateway, as well as at a Modbus RTU or CANopen master.



18014401443154187

- | | |
|---|---|
| [A] Bus connection | [D] Splitter |
| [B] CANopen (SBus gateway e.g. DFX/ UOH) or Modbus RTU master | [E] Connection cable |
| [C] Connection cable | [F] Y connector with terminating resistor |

Available cable sets

Cable sets with the matching components are available for connecting controllers, gateways and LT inverters. Refer to the "MOVITRAC® LTE-B" catalog for further information.

Sbus/CANopen cable length

The permitted total cable length depends on the baud rate set in parameter *P-36*:

- 125 kBd: 500 m
- 250 kBd: 250 m
- 500 kBd: 100 m
- 1000 kBd: 25 m

5 Startup

5.1 Brief instructions


A brief instruction for startup is available in the IP20 housing in a separate tray above the display. In IP55/IP66 housings, the brief instruction for startup is attached inside the front cover.

This brief instruction contains a wiring diagram for the signal terminals.

5.2 User interface

5.2.1 Keypad






Each MOVITRAC® LT inverter is equipped with a keypad that allows for operating and setup of the frequency inverter without any further devices.



2933664395

- | | |
|-------------------------------|---------------------|
| [1] 6-digit 7-segment display | [4] Navigate button |
| [2] Start button | [5] Up button |
| [3] Stop/Reset button | [6] Down button |

The keypad has 5 keys with the following functions:

- | | | |
|---|--------------|---|
| Key  | Navigate [4] | <ul style="list-style-type: none"> • Switch menu • Save parameter values • Display real time information |
| Key  | Up [5] | <ul style="list-style-type: none"> • Increase speed • Increase parameter values |
| Key  | Down [6] | <ul style="list-style-type: none"> • Decrease speed • Decrease parameter values |
| Key  | Stop [3] | <ul style="list-style-type: none"> • Stop drive • Acknowledge error |
| Key  | Start [2] | <ul style="list-style-type: none"> • Enable drive • Changing the direction of rotation |

If the parameters are set to the factory settings, the <Start> and <Stop> keys of the keypad are disabled. To enable using the <Start>/<Stop> buttons on the keypad, set the parameter *P-12* for LTE-B or *P1-12* for LTP-B to "1" or "2".

The parameter edit menu can only be accessed by pressing the <Navigate> key [4].

- To switch between the menu for changing parameters and real-time display (operating speed/operating current): keep the key pressed for longer than 1 second.
- Switch between operating speed and operating current of the running frequency inverter: press the key briefly (< 1 second).

5.2.2 Parameterization

Proceed as follows to change the parameter values:

1. Check the frequency inverter connection.

See chapter "Electrical Installation" (→ 20).


2. Make sure a the motor cannot start, e.g. by disconnecting terminal 1 from terminal 2.

3. Switch on the line voltage.


After the initialization, "StoP" is displayed.

StoP

INFORMATION: To allow for changing the parameters, the frequency inverter enable must be deactivated, e.g. by disconnecting terminal 1 from terminal 2.


4. Use the  key to activate the parameter mode.

P 1 - 0 1

(Press the  key for more than 1 s)

5. Use the  key and the  key to select the desired parameter.


P 1 - 0 3

6. Use the  key to activate the setting mode.


5.0

7. Use the  key and the  key to set the required parameter value.


2.0

8. Use the  key to quit the setting mode.

P 1 - 0 3

9. Use the  key to quit the parameter mode.

StoP





(Press the  key for more than 1 s)

The operator terminal shows "StoP", "H ", "A ", or "P ".

Refer to chapter "Parameters" (→ 67) for a detailed description of the parameters.

5.2.3 Resetting parameters to default settings

To reset the parameters to their default value, proceed as follows:

1. The frequency inverter must not be enabled and "Inhibit" must be shown on the display.
2. Press the 3 keys , , and  simultaneously for at least 2 s.
"P-deF" is shown on the display.
3. Press the  key to acknowledge the "P-deF" message.

5.3 Simple startup

1. Connect the motor to the frequency inverter. Note the nominal voltage of the motor when establishing the connection.
2. Enter the nominal values specified on the motor nameplate:
 - Use *P-01* and *P-02* to set the limit values for the minimum and maximum speed.
 - Use *P-03* and *P-04* to set the acceleration and deceleration times.
 - Use *P-07* to set the nominal motor voltage.
 - Use *P-08* to set the nominal motor current.
 - Use *P-09* to set the rated motor frequency.

5.3.1 Terminal mode (factory setting)

To activate the operation in terminal mode (factory setting), perform the following steps:

- Make sure that *P-12* is set to "0" (factory setting).
- Install a switch between terminals 1 and 2 on the user terminal block. See chapter Overview of signal terminals.
- Connect a potentiometer (1 k – 10 k) between Terminal 5, 6 and 7, with the sliders connected to terminal 6. See chapter Overview of signal terminals.

WARNING

Automatic motor run-up during startup

Severe or fatal injuries.

- Make sure that an automatic restart of the machine represents no danger to people or equipment.
 - Set the potentiometer to 0.
-
- Close the switch to enable the frequency inverter.
 - Set the speed using the potentiometer.



5.3.2 Keypad mode

In keypad mode, the drive can be controlled via the integrated operator terminal.

To activate operation in keypad mode, proceed as follows:

- Change parameter *P-12* to "1" (unidirectional) or "2" (bidirectional).
- Connect terminals 1 and 2 on the user terminal block with wire or a switch in order to enable the frequency inverter.
- Press the <Start> key. The frequency inverter is activated as 0 Hz.
- To increase the speed, press the <Up> key.
- Press the <Stop> key to stop the frequency inverter.
- If you now press the <Start> key, the frequency inverter returns to its original speed.

When bidirectional mode is activated (*P-12* = 2), pressing the <Start> key changes the direction of rotation.

• **▲ CAUTION!**

If you set the desired speed via the keypad during operation and subsequently press the <Stop/Reset> key, the frequency inverter resumes the previously set speed if you press the <Start> key again.

5.4 Startup in VFC vector control

The operation of motors with VFC vector control enables a better motor control behavior, and better torque performance, especially in the lower speed range. Operation in VFC vector control is mandatory for synchronous motors.

5.4.1 Startup of asynchronous motors

INFORMATION



During the connection, adhere to the nominal motor voltage.

1. Connect the motor to the frequency inverter.
2. Enter the motor data indicated on the motor nameplate:
 - *P-07* = nominal voltage of the motor
 - *P-08* = rated current of the motor
 - *P-09* = rated frequency of the motor
 - *P-10* = rated speed of the motor
3. Set the required VFC vector control.
 - *P-14* = 101 (extended menu)
 - *P-51* = 0 (VFC – ASM speed control)
4. Set the maximum and minimum speed using *P-01* and *P-02*.
5. Set the acceleration and deceleration ramps using *P-03* and *P-04*.
6. Start the automatic motor measurement procedure auto tune.
 - *P-52* = 1 (Start auto tune)



▲ WARNING

When parameter *P-52* is set to "1" (auto tune) the motor may start up automatically.

Severe or fatal injuries

- Do not touch the motor shaft

7. To optimize the control behavior, adjust the motor parameters (*P-53* – *P-57*), if necessary.

5.4.2 Startup of synchronous motors

INFORMATION



The operation of synchronous motors without encoder must be checked in a test application. Stable operation in this operating mode cannot be ensured for all application cases. Using this operating mode is thus in the sole responsibility of the user.

INFORMATION



During the connection, adhere to the nominal motor voltage.

1. Connect the motor to the frequency inverter. During the connection, adhere to the nominal motor voltage.
2. Enter the motor data indicated on the motor nameplate:
 - *P-07* = EMF → For synchronous motors, *P-07* is not used to set the system voltage, but the internal voltage for nominal speed.
 - *P-08* = rated current of the motor
 - *P-09* = rated frequency of the motor
 - *P-10* = rated speed of the motor
3. Set the required VFC vector control.
 - *P-14* = 101 (extended menu)
4. *P-51* = 2, 3 or 4, depending on the motor type (see "Advanced parameter description" (→ 71))
5. Set the maximum and minimum speed using *P-01* and *P-02*.
6. Set the acceleration and deceleration ramps using *P-03* and *P-04*.
7. Start the automatic motor measurement procedure auto tune.
 - *P-52* = 1 (Start auto tune)

▲ WARNING

When parameter *P-52* is set to "1" (auto tune) the motor may start up automatically.

Severe or fatal injuries.

- Do not touch the motor shaft.

8. To optimize the control behavior, adjust the motor parameters (*P-53* – *P-57*), if necessary.



9. If a higher torque is required in the lower speed range, the torque boost $P-11$ can be adjusted. The torque boost has the factor $4 \times P-11 \times P-08$. Note that the motor may heat up significantly due to the increased current flow.

5.4.3 Startup of LSPM motors

To operate an LSPM motor by SEW-EURODRIVE at the LTE-B+ inverter, proceed as follows:

INFORMATION



During the connection, adhere to the nominal motor voltage.

1. Connect the motor to the frequency inverter.
2. Enter the motor data indicated on the motor nameplate:
 - $P-07$ = nominal voltage of the motor
 - $P-08$ = rated current of the motor
 - $P-09$ = rated frequency of the motor
 - $P-10$ = rated speed of the motor
3. Set the required VFC vector control.
 - $P-14$ = 101 (extended menu)
 - $P-51$ = 5 (LSPM motor control)
4. Set the maximum and minimum speed using $P101$ and $P-02$.
5. Set the acceleration and deceleration ramps using $P-03$ and $P-04$.
6. Start the automatic motor measurement procedure auto tune.
7. $P-52$ = 1 (Start "Auto Tune")

▲ WARNING



When parameter $P-52$ is set to "1" (auto tune) the motor may start up automatically.

Severe or fatal injuries

- Do not touch the motor shaft

8. To optimize the control behavior, adjust the motor parameters ($P-53$ – $P-57$), if necessary.
9. If a higher torque is required in the lower speed range, the torque boost $P-11$ can be adjusted. This has the factor $4 \times P-11 \times P-08$. Note that the motor may heat up significantly due to the increased current flow.


5.5 Startup with PC

For startup using a PC the software "LT Shell V4.0" is available for download on www.sew-eurodrive.com.

5.5.1 PC connection

The diagnostic interface can be connected to a conventional PC/laptop with the following accessories:

- Interface adapter USB11A
- PC engineering set (cable set C) for the frequency inverter.



13129911435

- [1] Cable USB A-B
- [2] USB11A
- [3] RJ10 to RJ10 cable
- [4] RJ adapter (2 x RJ45, 1 x RJ10)
- [5] RJ45 to RJ45 cable

Type	Part number	Scope of delivery
USB11A	08248311	<ul style="list-style-type: none"> • Interface adapter USB11A • USB cable • Cable with RJ10 – RJ10 plug connectors
PC engineering set	18243681	<ul style="list-style-type: none"> • Adapter OP LT 003 C with voltage converter DC 24 V → DC 5 V • Cable with RJ45 – RJ45 plug connectors

5.6 Startup via fieldbus

5.6.1 SBus startup

Install the SBus network according to the figure in chapter Fieldbus configuration.

- Startup the inverter as described in section "Easy startup" (→ 42).
- Set parameter *P-12* to "3" or "4" to control the frequency inverter via SBus.
 - 3 = Control word and speed setpoint via SBus, ramp times as specified in *P-03/P-04*.
 - 4 = Control word, speed setpoint and ramp time via SBus.
- Set *P-14* to "101" to obtain access to the advanced menu.
- Set the values in *P-36* as follows:
 - Set a unique SBus address between "1" and "63".
 - The SBus baud rate is set to 500 baud at the factory (factory setting). To set a different baud rate, set it in *P-36*. Note that the baud rate of SBus gateway and frequency inverter must always be identical.
 - Determine the frequency inverter's response to timeout, when the communication is interrupted:
 - 0: Continue with the data used last (factory setting).
 - t_xxx: Error after delay of xxx milliseconds. The error must be reset.
 - r_xxx: The frequency inverter is stopped along a ramp when the time of xxx milliseconds is exceeded. An automatic restart is performed when new data is received.
- Connect the frequency inverter to the DFx/UOH gateway via SBus as described in section Communication socket RJ45.
- Set DIP switch "AS" on the DFx/UOH gateway from "OFF" to "ON" to perform an auto-setup for the fieldbus gateway. The "H1" LED on the gateway lights up repeatedly and then goes off completely. When the "H1" LED is lit, the gateway or one of the frequency inverters at the SBus has not been wired properly or has not been taken into operation properly.
- Refer to the relevant DFx manual for information on how to establish fieldbus communication between DFx/UOH gateway and bus master.

Permitted cable lengths

The permitted total cable length depends on the baud rate setting of the SBus:

- 125 kBd: 500 m
- 250 kBd: 250 m
- 500 kBd: 100 m (factory setting)
- 1000 kBaud: 25 m


Use only shielded cables.

Monitoring sent data

The data transmitted via the gateway can be monitored by one of the following methods:

- Using MOVITOOLS® MotionStudio via the X24 engineering interface of the gateway or optionally via Ethernet
- Via the website of the gateway (e.g. on DFE3x Ethernet gateways)

Structure of SBus telegram



5.6.2 CANopen startup

Set up the CANopen network according to figure in chapter "Fieldbus configuration" (→ 39).

- Startup the inverter as described in chapter "Simple startup" (→ 42).
- Set parameter *P-12* to "7" or "8" to control the frequency inverter via CANopen.
 - 7 = Control word and speed setpoint via CANopen, ramp times as specified in *P-03/P-04*.
 - 8 = Control word, speed setpoint and ramp time via CANopen.
- Set parameter *P-14* to "101" to obtain access to the advanced menu.
- Set the values in *P-36* as follows:
 - Set a unique address between "1" and "63".
 - The baud rate is set to "500 kBd" at the factory (factory setting). To set a different baud rate, set it in *P-36*. Note that the baud rate of master and frequency inverter must always be identical.
 - Determine the frequency inverter's response to timeout, when the communication is interrupted:
 - 0: Continue with the data used last (factory setting).
 - *t_xxx*: Error after delay of xxx milliseconds. The error must be reset.
 - *r_xxx*: The frequency inverter is stopped along a ramp when the time of xxx milliseconds is exceeded. An automatic restart is performed when new data is received.
- Connect the frequency inverter to a CANopen master as described in section "Communication socket RJ45" (→ 31) and chapter "Fieldbus configuration" (→ 39).

Specification

CANopen communication is implemented in accordance with the specification DS301 version 4.02 of CAN in automation (see www.can-cia.de). A specific unit profile, such as DS 402, is not implemented.

COB IDs and functions in the frequency inverter

The CANopen profile provides the following COB ID (Communication Object Identifier) and functions:

Messages and COB IDs		
Type	COB ID	Function
NMT	000h	Network management
Sync	080h	Synchronous message with dynamically configurable COB ID
Emergency	080h + device address	Emergency message with dynamically configurable COB ID
PDO1 ¹⁾ (Tx)	180h + device address	PDO (Process Data Object) PDO1 is pre-mapped and activated by default. PDO2 is pre-mapped and activated by default. Transmission mode (synchronous, asynchronous, event), COB ID and mapping can be configured as required.
PDO1 (Rx)	200h + device address	
PDO2 (Tx)	280h + device address	
PDO2 (Rx)	300h + device address	
SDO ²⁾	580h + device address	SDO channel for parameter data exchange with the CANopen master
SDO (Rx) ²⁾	600h + device address	
Error control	700h + device control	Guarding and heartbeat functions are supported. COB ID can be set to another value.

- 1) The frequency inverter supports up to 2 process data objects (PDO). All PDOs are pre-mapped and active with transmission mode 1 (cyclical and synchronous). This means that the TX-PDO is sent after every SYNC pulse regardless of whether the content of the TX-PDO has changed or not.
- 2) The frequency inverter SDO channel supports only expedited transmission. The SDO mechanisms are described in detail in the CANopen specification DS301.

INFORMATION



Transmitting speed, current or similar values that change quickly via Tx-PDO results in a very high load on the bus.

To limit the bus load to predictable values, you can use the inhibit time, see section "Inhibit time" in the "MOVIDRIVE® MDX60B/61B Communication and Fieldbus Device Profile" manual.

- Tx (transmit) and Rx (receive) are depicted from perspective of the slave.

Supported transmission modes

The various transmission types can be selected for every process data project (PDO) in network management (NMT).

The following transmission types are supported for Rx PDOs:

Rx PDO transmission mode		
Transmission type	Mode	Description
0 – 240	Synchronous	The received data is transmitted to the frequency inverter as soon as the next synchronization message is received.
254, 255	Asynchronous	The received data is transmitted to the frequency inverter without delay.

The following transmission types are supported for Tx PDOs:

Tx PDO transmission type		
Transmission type	Mode	Description
0	Acyclic synchronous	Tx PDO is transmitted only if the process data has changed and a SYNC object has been received.
1 – 240	Cyclic synchronous	Tx PDOs are transmitted synchronously and cyclically. The transmission type indicates the number of the SYNC object required for triggering transmission of the Tx PDO.
254	Asynchronous	Tx PDOs are transmitted only when the corresponding Rx PDO has been received.
255	Asynchronous	Tx PDOs are always transmitted as soon as the PDO data has changed.

Default allocation plan of process data objects (PDO)

The following table shows the default mapping of the PDOs:

PDO default mapping					
	Object no.	Mapped object	Length	Mapping with default setting	Transmission type
Rx PDO1	1	2010h	Unsigned 16	PO1 control word	1
	2	2012h	Integer 16	PO2 setpoint speed	
	3	0006	Unsigned 16	Reserved	
	4	2014h	Unsigned 16	PO3 ramp time	
Tx PDO1	1	2110h	Unsigned 16	PI1 status word	1
	2	2112h	Integer 16	PI2 actual speed	
	3	2113h	Unsigned 16	PI3 actual current	
	4	2114h	Integer 16	PI4 motor torque	
Rx PDO 2	1	0006h	Unsigned 16	Reserved	1
	2	0006h	Unsigned 16	Reserved	
	3	0006h	Unsigned 16	Reserved	
	4	0006h	Unsigned 16	Reserved	
Tx PDO2	1	2118h	Unsigned 16	Status analog input 1	1
	2	2119h	Integer 16	Status analog input 2	
	3	211Ah	Unsigned 16	Status of digital inputs and outputs	
	4	2116h	Unsigned 16	Frequency inverter temperature	

INFORMATION



Tx (transmit) and Rx (receive) are depicted from perspective of the slave.

Note: Modified default settings are lost after power off and on again. This means the settings are restored to default values after power off.

Table of CANopen-specific objects

CANopen-specific objects						
Index	Sub index	Function	Access	Type	PDO map	Default value
1000h	0	Device type	RO	Unsigned 32	N	0

CANopen-specific objects						
Index	Sub index	Function	Access	Type	PDO map	Default value
1001h	0	Error register	RO	Unsigned 8	N	0
1002h	0	Manufacturer status register	RO	Unsigned 16	N	0
1005h	0	COB-ID Sync	RW	Unsigned 32	N	00000080h
1008h	0	Manufacturer device name	RO	String	N	"LTEB" or "LT1B"
1009h	0	Manufacturer hardware version	RO	String	N	x.xx (e.g. 1.00)
100Ah	0	Manufacturer software version	RO	String	N	x.xx (e.g. 2.00)
100Ch	0	Guard time [1 ms]	RW	Unsigned 16	N	0
100Dh	0	Life time factor	RW	Unsigned 8	N	0
1014h	0	COB-ID EMCY	RW	Unsigned 32	N	00000080h+Node ID
1015h	0	Inhibit time emergency [100 µs]	RW	Unsigned 16	N	0
1017h	0	Producer heart beat time [1 ms]	RW	Unsigned 16	N	0
1018h	0	Identity object no. of entries	RO	Unsigned 8	N	4
	1	Vendor ID	RO	Unsigned 32	N	0x00000059
	2	Product code	RO	Unsigned 32	N	Drive depended
	3	Revision number	RO	Unsigned 32	N	x.xx
	4	Serial number	RO	Unsigned 32	N	e.g. 1234/56/789
1200h	0	SDO parameter no. of entries	RO	Unsigned 8	N	2
	1	COB-ID client -> server (RX)	RO	Unsigned 32	N	00000600h+Node ID
	2	COB-ID server -> client (TX)	RO	Unsigned 32	N	00000580h+Node ID
1400h	0	RX PDO1 comms param no. of entries	RO	Unsigned 8	N	2
	1	RX PDO1 COB-ID	RW	Unsigned 32	N	40000200h+Node ID
	2	RX PDO1 transmission type	RW	Unsigned 8	N	1
1401h	0	RX PDO2 comms param no. of entries	RO	Unsigned 8	N	2
	1	RX PDO2 COB-ID	RW	Unsigned 32	N	40000300h+Node ID
	2	RX PDO2 transmission type	RW	Unsigned 8	N	1
1600h	0	RX PDO1 mapping / no. of entries	RW	Unsigned 8	N	4
	1	RX PDO1 1 st mapped object	RW	Unsigned 32	N	20100010h
	2	RX PDO1 2 nd mapped object	RW	Unsigned 32	N	20120010h
	3	RX PDO1 3 rd mapped object	RW	Unsigned 32	N	00060010h
	4	RX PDO1 4 th mapped object	RW	Unsigned 32	N	20140010h
1601h	0	RX PDO2 mapping / no. of entries	RW	Unsigned 8	N	4
	1	RX PDO2 1 st mapped object	RW	Unsigned 32	N	00060010h
	2	RX PDO2 2 nd mapped object	RW	Unsigned 32	N	00060010h
	3	RX PDO2 3 rd mapped object	RW	Unsigned 32	N	00060010h
	4	RX PDO2 4 th mapped object	RW	Unsigned 32	N	00060010h
1800h	0	TX PDO1 comms param no. of entries	RO	Unsigned 8	N	3
	1	TX PDO1 COB-ID	RW	Unsigned 32	N	40000180h+Node ID
	2	TX PDO1 transmission type	RW	Unsigned 8	N	1
	3	TX PDO1 Inhibit time [100 µs]	RW	Unsigned 16	N	0
1801h	0	TX PDO2 comms param no. of entries	RO	Unsigned 8	N	3
	1	TX PDO2 COB-ID	RW	Unsigned 32	N	40000280h+Node ID
	2	TX PDO2 transmission type	RW	Unsigned 8	N	1
	3	TX PDO2 Inhibit time [100 µs]	RW	Unsigned 16	N	0
1A00h	0	TX PDO1 mapping / no. of entries	RW	Unsigned 8	N	4
	1	TX PDO1 1 st mapped object	RW	Unsigned 32	N	21100010h
	2	TX PDO1 2 nd mapped object	RW	Unsigned 32	N	21120010h
	3	TX PDO1 3 rd mapped object	RW	Unsigned 32	N	21130010h
	4	TX PDO1 4 th mapped object	RW	Unsigned 32	N	21140010h
1A01h	0	TX PDO2 mapping / no. of entries	RW	Unsigned 8	N	4
	1	TX PDO2 1 st mapped object	RW	Unsigned 32	N	21180010h

CANopen-specific objects						
Index	Sub index	Function	Access	Type	PDO map	Default value
	2	TX PDO2 2 nd mapped object	RW	Unsigned 32	N	21190010h
	3	TX PDO2 3 rd mapped object	RW	Unsigned 32	N	211A0010h
	4	TX PDO2 4 th mapped object	RW	Unsigned 32	N	21160010h

Table of manufacturer-specific objects

The manufacturer-specific objects of the frequency inverter are defined as follows:

Manufacturer-specific objects						
Index	Sub index	Function	Access	Type	PDO map	Note
2000h	0	Reserved	RW	Unsigned 16	Y	Read as 0, writing not possible
2001h – 200Fh	0	Reserved	RW	Unsigned 16	Y	Read as 0, writing not possible
2010h	0	Control command register	RW	Unsigned 16	Y	S-Bus control word format
2011h	0	Speed reference (RPM)	RW	Integer 16	Y	1 = 0.2 1/min
2012h	0	Speed reference (percentage)	RW	Integer 16	Y	4000HEX = 100 % P1-01
2013h	0	Reserved	RW	Integer 16	Y	Read as 0, writing not possible
2014h	0	User ramp reference	RW	Unsigned 16	Y	1 = 1 ms (reference to 50 Hz)
2015h – 2100h	0	Reserved	RW	Unsigned 16	Y	Read as 0, writing not possible
2101h – 210Fh	0	Reserved	RO	Unsigned 16	Y	Read as 0
2110h	0	Drive status register	RO	Unsigned 16	Y	S-Bus status word format
2111h	0	Motor speed (RPM)	RO	Integer 16	Y	1 = 0.2 1/min
2112h	0	Motor speed (percentage)	RO	Integer 16	Y	4000HEX = 100 % von P-01
2113h	0	Motor current	RO	Unsigned 16	Y	4000HEX = 100 % von P-08
2114h	0	Motor torque	RO	Integer 16	Y	1000DEC = Motor rated torque
2115h	0	Motor power	RO	Unsigned 16	Y	1000DEC = Drive rated power
2116h	0	Drive temperature	RO	Integer 16	Y	1DEC = 0.01 °C
2117h	0	DC bus value	RO	Unsigned 16	Y	1DEC = 1 V
2118h	0	Analog input 1	RO	Integer 16	Y	1000HEX = Full scale
2119h	0	Analog input 2	RO	Integer 16	Y	1000HEX = Full scale
211Ah	0	Digital input & output status	RO	Unsigned 16	Y	LB = input, HB = output
211Bh	0	Analog output 1 (percentage)	RO	Unsigned 16	Y	1000 DEC = 100.0 %
211Ch – 2120h	0	Reserved	RO	Unsigned 16	Y	Read as 0
2121h	0	Scope channel 1 (internal format)	RO	Unsigned 16	Y	
2122h	0	Scope channel 2 (internal format)	RO	Unsigned 16	Y	
2123h	0	Scope channel 3 (internal format)	RO	Unsigned 16	Y	
2124h	0	Scope channel 4 (internal format)	RO	Unsigned 16	Y	
2AF8h ¹⁾	0	S-Bus parameter start index	RO	–	N	11000d
–	0	S-Bus parameters	RO/RW	–	N	–
2C6Fh ¹⁾	0	S-Bus parameter end index	RW	–	N	11375d

1) Objects 2AF8h – 2C6EF correspond with SBus parameter indexes 11000d – 11375d, some of them are read-only.

5.6.3 Startup of modbus RTU

Protocol	Modbus RTU (Remote Terminal Unit)
Error checking	CRC
Baud rate	9600 bps, 19,200 bps, 38,400 bps, 57,600 bps, 76,800 bps, 115,200 bps (standard)
Data format	1 start bit, 8 data bits, 1 stop bit, no priority
Physical format	RS485 (2-core)
User interface	RJ45

Electrical installation

Install the Modbus network according to the figure in chapter Fieldbus configuration. The maximum number of bus nodes is 32. The permitted cable length depends on the baud rate. With a baud rate of 115 200 bps and a 0.5 mm² cable, the maximum cable length is 1200 m. For the connection assignment for the RJ45 communication socket, refer to chapter Communication socket RJ45.

- Startup the frequency inverter as described in section "Easy startup" (→ 42).
- Set parameter *P-12* to "5" or "6" to control the frequency inverter via Modbus RTU.
 - 5 = Control word and speed setpoint via Modbus RTU, ramp times as specified in *P-03/P-04*.
 - 6 = Control word, speed setpoint and ramp time via Modbus RTU.
- Set *P-14* to "101" to obtain access to the advanced menu.
- Set the values in *P-36* as follows:
 - Set a unique Modbus address between "1" and "64".
 - The Modbus baud rate is set to "115.2 kBd" at the factory (factory setting). To set a different baud rate, set it in *P-36*. Note that the baud rate of modbus master and frequency inverter must always be identical.
 - Determine the frequency inverter's response to timeout, when the communication is interrupted.
 - 0: Continue with the data used last (factory setting).
 - *t_xxx*: Error after a delay of xxx milliseconds, error must be reset.
 - *r_xxx*: The frequency inverter is stopped along a ramp when the time of xxx milliseconds is exceeded. An automatic restart is performed when new data is received.
- Connect the frequency inverter to a suitable Modbus master as described in section Communication socket RJ45. For startup of the Modbus master, refer to the relevant chapter in the manufacturer's operating instructions.

Register allocation of the process data words

The following table shows the most important registers for easy control.

For the structure of the process data words PI and PO, refer to chapter "Description of transmitting process data (PD)" (→ 57).

Re-gister	Process data	Com-mand	Type
1	PO1 control word (fixed; data byte assignment, see Process data words (16 bit) from gateway to inverter (PA))	03, 06	Read/write
2	PO2 setpoint speed (data byte assignment, see Process data words (16 bit) from gateway to inverter (PA))	03, 06	Read/write
3	PO3 ramp (if $P-12 = 6$; data byte assignment, see Process data words (16 bit) from gateway to inverter (PA))	03, 06	Read/write
4	Reserved	03, 06	Read/write
5	Reserved	0, 3	Read
6	PI1 status word (fixed; data byte assignment, see "Process data words (16 bit) from inverter to gateway (PI)" (→ 57))	0, 3	Read
7	PI2 actual speed (data byte assignment, see "Process data words (16 bit) from inverter to gateway (PI)" (→ 57))	0, 3	Read
8	PI3 actual current (data byte assignment, see "Process data words (16 bit) from inverter to gateway (PI)" (→ 57))	0, 3	Read

You find the complete allocation of parameters and registers as well as the scaling of data in the memory allocation plan in chapter "Overview of parameters" (→ 67).

INFORMATION



Note: Many bus masters address the first register as register 0. Thus it may be necessary to subtract the value "1" from the register number listed below, to obtain the correct register address.

Structure of Modbus telegram

Structure of process data

For a read request

Request master → slave

Address	Function	Data				CRC check
		Start address		Number of registers		
addr	03 _H	High byte	Low byte	High byte	Low byte	crc16

Response slave → master

Address	Function	Data		CRC check
		Number of data bytes	Information	
addr	03 _H	n (8 bit)	n/2 register	crc16

For a write command

Request master → slave

Address	Function	Data				CRC check
		Register number		Process data		
addr	06 _H	High byte	Low byte	High byte	Low byte	crc16

Response slave → master

Address	Function	Data				CRC check
		Register number		Process data		
addr	06 _H	High byte	Low byte	High byte	Low byte	crc16

Communication example

Sending of setpoints

- Enable
- Motor speed = 100%
- Ramp = 5 s

As a response, the slave sends confirmation of the sent information in a corresponding telegram.

Enable

Data direction	Address	Function	Data	CRC check
-Tx	01	06 _H	00010006	09C8
-Rx	01	06 _H	00010006	09C8

Motor speed

Data direction	Address	Function	Data	CRC check
-Tx	01	06 _H	00024009	29CC
-Rx	01	06 _H	00024009	29CC

Acceleration ramp

Data direction	Address	Function	Data	CRC check
-Tx	01	06 _H	00031388	255C
-Rx	01	06 _H	00031388	255C

Tx – Send from perspective of the bus master

Rx – Receive from perspective of the bus master

Explanation of write command using example of enable

Address	01 _H – unit address
Function	06 _H – write
Data	00010006 _H – write to register 01, value 06 _H = enable
CRC check	CRC_high, CRC_low

5.6.4 Description of transferred process data (PD)

Structure of process data words

This chapter describes the structure of the process data words for the fieldbus communication with SBus and Modbus RTU.

Process data words (16 bit) from gateway to inverter (PA)

Description	Bit	Settings
PO1	Control word	0: Start 1: Stop
	1	Rapid stop along the second deceleration ramp (<i>P-24</i>)
	2	Stop along process ramp <i>P-03/P-04</i> or PO3
	3 – 5	Reserved
	6	Error reset
	7 – 15	Reserved
PO2	Setpoint speed	Signed percentage value / 0.0061% Example: -80%/0.0061% = -13115 = CCC5 (Hex)
PO3	Ramp time (if <i>P-12</i> = 4, 6 or 8)	Time from 0 – 50 Hz in ms (range 100 – 65535 ms). 1 digit = 1 ms Example: 1.0 s = 1000 ms = 03E8 _{hex}
	No function (if <i>P-12</i> = 3, 5 or 7)	Ramp time set as in <i>P-03</i> and <i>P-04</i> .

Process data words (16 bit) from inverter to gateway (PI)

Description	Bit	Settings	Byte
PI1	Status word	0: Disabled 1: Enabled	Low byte
	1	Inverter ready	
	2	PO data enabled	
	3 – 4	Reserved	
	5	Fault/warning	
	6 – 7	Reserved	
	8 – 15	Inverter status, if bit 5 = 0 0x01 = Output stage inhibited 0x02 = Not enabled/not running 0x04 = Enabled/running 0x05 = Factory setting activated	High byte
	8 – 15	Inverter status, if bit 5 = 1 0x01 = Output stage inhibited 0x04 = Not enabled/not running 0x06 = Error phase asymmetry input/input-phase failure 0x07 = Overvoltage at the DC bus 0x08 = Motor overload 0x09 = Parameter to factory settings 0x0B = Switch-off due to overtemperature 0x1A = external error 0x2F = Error communication connection failure (SBus) 0x71 = Error analog input, current below 2.5 mA 0x75 = Switch-off due to undertemperature 0x07 = Undervoltage at the DC bus 0xC8 = General error/output stage error	
PI2	Actual speed	Scaling equals PO2	
PI3	Actual current	Scaling: 0x4000 = 100% of the maximum speed as set in <i>P-08</i>	

Example

The information listed in the following table are transmitted to the inverter if the following conditions are met:

- To enable the inverter, the digital inputs must be correctly configured and connected.
- If the inverter is operated via SBus, the parameter *P-12* must be set to 3 or 5.

Description		Value	Description
PO1	Control word	0	Rapid stop along the second deceleration ramp (<i>P-24</i>).
		1	Coast to a stop
		2	Stop along the process ramp (<i>P-04</i>)
		3 – 5	Reserved
		6	Startup along a ramp (<i>P-03</i>) and with rotating setpoint speed (<i>PO2</i>).
PO2	Speed setpoint	0x4000	= 16 384 = max. speed, e.g. 50 Hz (<i>P-01</i>) CW rotation
		0x2000	= 192 = 50% of the max. speed, e.g. 25 Hz CW rotation
		0xC000	= -16 384 = max. speed, e.g. 50 Hz (<i>P-01</i>) CCW rotation
		0x0000	= 0 = min. speed, set in <i>P-02</i>

The data sent by the inverter should look as follows during operation:

Description		Value	Description
PI1	Status word	0x0407	Status = running Output stage enabled Inverter ready Enable PO data
PI2	Actual speed	Set according to PO2 (speed setpoint)	
PI3	Actual current	Depending on speed and load	

5.7 Startup with 87 Hz characteristic curve

The following parameters have to be set:

- P-01: 87 Hz
- P-07: 400 V
- P-08: Motor current for Δ operation (see nameplate)
- P-09: 87 Hz

5.8 Additional functions for startup

5.8.1 Fire mode/emergency mode

Enabling the fire mode input has the frequency inverter drive the motor with the preset values. In this mode, the frequency inverter ignores all faults and shutdowns and operates the motor until the frequency inverter is destroyed or even until the loss of voltage supply.

Set the fire mode as follows:

1. Perform a motor startup.
2. Set parameter *P-14* to "101" to being able to access further parameters.
3. Select parameter *P-15* = 13 to activate the fire mode function.

INFORMATION




A detailed description of the binary file configuration when *P-15* = 13, see chapter "P-15 Binary input function selection" (→ 90). The input functions in *P-15* depend on the settings in *P-12*.

4. Set parameter *P-60* to the speed that is to be used in fire mode.

5.8.2 PI controller mode

The integrated PI controller allows for realizing a simple sensor actuator closed loop system. For example, the pressure of a unit can be regulated, when the drive controls a pump and the PI controller receives feedback via a pressure transducer.

The following diagram shows the basic startup procedure of the integrated PI controller. For further information on the individual parameters, refer to chapter "Advanced parameter description" (→ 71).




16873132043

22511067/EN – 04/2016

5.8.3 Master-slave mode

Master-slave mode (P-12 = 11)



16873961867

[1] RJ45 to RJ45 cable

[2] Cable splitter

The frequency inverter has an integrated master slave function. The master-slave communication is obtained via a special protocol. In this case, the frequency inverter communicates via the RS485 engineering interface. Up to 63 frequency inverters can be connected with one another in a communication network using RJ45 connectors. One frequency inverter is configured as master, the remaining frequency inverters as slaves. Each network may have only one master frequency inverter. This master frequency inverter sends its operating state (such as stopped, running) and output frequency every 30 ms. The slave frequency inverters then follow the state of the master frequency inverter.

Configuring the master frequency inverter

The master frequency inverter of each network must have the communication address "1". Set:

- $P-12 \neq 11$
- $P-14 = 101$
- $P-36/1 = 1$ (inverter address 1 = factory setting)

Configuring the slave frequency inverters

Each connected slave must have a unique slave communication address that is set in $P-36$. You can assign slave addresses from 2 to 63. Set:

- $P-12 = 11$
- $P-14 = 101$
- in $P-35$ the slave scaling factor

6 Operation

6.1 Status of the inverter

6.1.1 Display for inhibited inverter

The following table shows the messages relating to the inverter status that are displayed when the motor is at standstill.

Message	Description
StoP	Power section of inverter disabled. This message is displayed when the motor is at standstill and no error is present. The inverter is ready for normal operation.
P-deF	Parameter factory settings have been loaded. This message appears when the user issues the command for loading the parameter factory settings. To take the inverter into operation again, press the <Reset> key.
Standby	Inverter is in standby mode. This message is displayed when the inverter reports a speed of 0 for 30 seconds and the speed setpoint is also 0.

6.1.2 Display for enabled inverter

The following table shows the messages relating to the frequency inverter status that are displayed when the motor is running.

You can toggle between output frequency, output current, and speed by briefly pressing the <Navigate> key on the keypad.

Message	Description
H xxx	The output frequency of the frequency inverter is displayed in Hz. Displayed, when the frequency inverter is enabled.
A xxx	The output current of the frequency inverter is displayed in amperes. Displayed, when the frequency inverter is enabled.
xxxx	The frequency inverter output speed is displayed in 1/min, when a value > 0 was entered in <i>P-10</i> .
C xxx	The scaled speed (<i>P-40</i>).
..... (flashing dots)	The output current of the frequency inverter exceeds the current value entered in <i>P-08</i> . The frequency inverter monitors load and duration of the overload. The frequency inverter triggers error message "I.t-trP" depending on the overload.

6.1.3 Error reset

You can reset an error in the event of an error response (see section "Error codes" (→ 63)) by pressing the <Stop> key or by enabling or disabling digital input 1.

7 Service and error codes

7.1 Fault memory

In parameter mode, parameter *P00-28* contains a data set with the last four events that have occurred. The relevant messages are only displayed in brief form, with the latest message first (when *P00-28* is opened). Older messages are moved downward.

Once a new message is issued, the oldest message is deleted from the error log.

INFORMATION



If the last shutdown was caused, for example, by undervoltage, no further undervoltage errors will be entered in the error log. The purpose is to avoid that the error log is flooded with undervoltage errors, which occur every time the inverter is switched off.

7.2 Error codes

Error message	Error code Status word, when bit Xy = 1		CANopen Emergency Code	Meaning	Measure
	dec	hex			
Inverter display			hex		
"O-I"	1	0x1	0x2303	Overcurrent at inverter output to the motor Motor overload Overtemperature at the heat sink of the inverter	Error during constant speed: • Check overload or fault Fault while enabling the inverter: • Check the motor for stalling or blocking • Check for star-delta motor connection error • Check whether the length of the cable meets the requirements Error during operation: • Check for sudden overload or malfunction • Check the cable connection between inverter and motor • The acceleration/deceleration time might be too short and requires too much power. If you cannot increase <i>P-03</i> or <i>P-04</i> , use a larger inverter.
"h-OI"	1	0x1	0x230F	Hardware overcurrent error at the inverter output (IGBT self-protection in case of overload).	
"I.t-trP"	8	0x08	0x1004	Overload error. This error occurs when the inverter has delivered more than 100 % of the nominal current for a certain time (defined in <i>P-08</i>). The display is flashing to indicate overload.	• Increase the acceleration ramp <i>P-03</i> or reduce the motor load. • Check whether the length of the cable meets the requirements. • Mechanically check the load to make sure it can be moved freely and no blockage or other mechanical problems are present.
"OI-b"	4	0x04	0x2301	Brake channel overcurrent Overcurrent in the braking resistor circuit	• Check supply cable to the braking resistor • Check braking resistance value • Observe the minimum resistance values given in the respective tables.
"OL-br"	4	0x04	0x1002	Braking resistor overload	• Increase deceleration time, reduce load moment of inertia or switch further braking resistors in parallel. • Observe the minimum resistance values given in the respective tables.

Error message	Error code Status word, when bit Xy = 1		CANopen Emergency Code	Meaning	Measure
	dec	hex			
Inverter display					
"PS-trP"	200	0xC8	0x1005	Internal output stage error	Fault while enabling the inverter: <ul style="list-style-type: none"> • Check for incorrect wiring or short circuit. • Check for phase short circuits or ground faults. Error during operation: <ul style="list-style-type: none"> • Check for sudden overload or overtemperature. • Provide an additional room or cooling, if necessary.
"O.Uolt"	7	0x07	0x3206	DC link overvoltage	<ul style="list-style-type: none"> • Check whether the supply voltage is too high or too low. • If the error occurs during deceleration, increase the deceleration time in <i>P-04</i>. • Connect a braking resistor, if required. • If a braking resistor is already installed, make sure that <i>P-34</i> is set to 1 or 2.
"U.Uolt"	198	0xC6	0x3207	DC link undervoltage	Occurs routinely when switching off the inverter. Check line voltage if this occurs while the motor is running.
"O-hEat"	124	0x7C	0x4117	Ambient temperature too high	<ul style="list-style-type: none"> • Check inverter cooling and housing dimensions. • Provide an additional room or cooling, if necessary. • Check internal fan function.¹⁾
"O-t"	11	0x0B	0x4208	Overtemperature at heat sink	<ul style="list-style-type: none"> • Check inverter cooling and housing dimensions. • Provide an additional room or cooling, if necessary. • Check internal fan function¹⁾. • Decrease the switching frequency. • Reduce the motor load.
"U-t"	117	0x75	0x4209	Undertemperature	<ul style="list-style-type: none"> • Occurs at an ambient temperature below -10 °C. • Increase the temperature to above -10 °C to start the inverter.
"E-triP"	26	0x1A	0x100B	External error (in conjunction with digital input 3).	<ul style="list-style-type: none"> • External error at digital input 3. NC contact was opened. • Check motor thermistor (if connected).
"SC-trP"	46	0x2E	0x100C	Communication failure error	<ul style="list-style-type: none"> • Check communication connection between inverter and external devices. • Make sure each inverter in the network is assigned a unique address.
"P-LOSS"	6	0x06	0x310E	Input phase failure error	An input phase failed in an inverter designed for operation on a three-phase system.
"dAtA-F"	98	0x62	0x1011	Internal memory error	<ul style="list-style-type: none"> • Parameter not saved, factor settings restored. • Try again. If this problem reoccurs, contact SEW-EURODRIVE Service.
"SC-FLt"	—	—	—	Internal inverter fault	Contact SEW-EURODRIVE Service if you have any questions.
"FAULtY"					
"Prog_ _"					
"Flt-dc"	7	0x07	0x320D	DC link ripple too high	Check the current supply.
"th-Flt"	31	0x1F	0x1010	Defective thermistor at heat sink	Contact SEW-EURODRIVE Service.
"4-20 F"	113	0x71	0x1012	Signal loss 4 – 20 mA	<ul style="list-style-type: none"> • Check whether the input current in <i>P-16</i> and <i>P248</i> lies within the defined range. • Check the signal cable
"F-Ptc"	31	0x1F	0x1015	PTC triggered	The connected PTC thermistor has triggered an inverter switch-off.
"FAn-F"	50	0x32	0x1016	Internal fan error.	Contact SEW-EURODRIVE Service.

Error message	Error code Status word, when bit Xy = 1		CANopen Emergency Code	Meaning	Measure
	dec	hex	hex		
Inverter display					
"AtF01"	81	0x51	0x1028	The measured stator resistance fluctuates between the phases.	The measured stator resistance of the motor is asymmetrical. Check to see, if: <ul style="list-style-type: none"> • The motor is connected correctly and without error. • The winding has the correct resistance and symmetry.
"AtF02"	81	0x51	0x1029	The measured stator resistance is too high.	The measured stator resistance of the motor is too high. Check to see, if: <ul style="list-style-type: none"> • The motor is connected correctly and without error. • The power rating of the motor corresponds with the power rating of the connected inverter.
"AtF03"	81	0x51	0x102A	Measured motor inductance too low.	The measured motor inductance is too low. Make sure that the motor is connected correctly and without error.
"AtF04"	81	0x51	0x102B	Measured motor inductance too high.	The measured motor inductance is too high. Check to see, if:
"AtF05"	81	0x51	0x102C	Timeout of inductance measurement	<ul style="list-style-type: none"> • The motor is connected correctly and without error. • The power rating of the motor corresponds with the power rating of the connected inverter.
"SC-F01"	43	0x2B	0x1032	Modbus communication error	Check the communication settings.
"SC-F02"	47	0x2F	0x1033	SBus/CANopen communication error	Check: <ul style="list-style-type: none"> • The communication connection between inverter and external devices. • The clearly assigned address per inverter in the network.

1) Press all keys of the integrated keypad simultaneously to check the frequency inverter function from 0.75 kW on.

7.3 SEW-EURODRIVE Electronics Service

If you are unable to rectify a fault, contact SEW-EURODRIVE Electronics Service.

Please provide the following information when sending the device in for repair:

- Serial number (→ nameplate)
- Type designation
- Short description of the application (application, control via terminals or serial)
- Connected components (motor, and so on)
- Type of error
- Circumstances
- Your own assumptions as to what has happened
- Any unusual events preceding the problem, and so on

7.4 Extended storage

If the unit is stored for a long time, connect it to the power supply for at least 5 minutes every 2 years. Otherwise, the unit's service life may be reduced.

Procedure when maintenance has been neglected:

Electrolytic capacitors are used in the frequency inverters. They are subject to aging effects when de-energized. This effect can damage the capacitors if the unit is connected directly to the nominal voltage after an extended storage period.

If you have not performed maintenance regularly, SEW-EURODRIVE recommends that you increase the line voltage slowly up to the maximum voltage. This can be done, for example, by using a variable transformer for which the output voltage has been set according to the following overview.

The following stages are recommended:

AC 230 V units:

- Stage 1: AC 170 V for 15 minutes
- Stage 2: AC 200 V for 15 minutes
- Stage 3: AC 240 V for 1 hour

AC 400 V units:

- Stage 1: AC 0 V to AC 350 V within a few seconds
- Stage 2: AC 350 V for 15 minutes
- Stage 3: AC 420 V for 15 minutes
- Stage 4: AC 480 V for 1 hour

After you have completed the regeneration process, the unit can be used immediately or stored again for an extended period with maintenance.

7.5 Waste disposal

Please observe current regulations. Dispose of the following materials in accordance with the regulations in force:

- Electronics scrap (printed circuit boards)
- Plastic (housing)
- Sheet metal
- Copper
- Aluminum

8 Parameters

8.1 Overview of parameters

8.1.1 Standard parameters

Speed limitations				
Modbus registers	SBus/CANopen Index	Parameters/description	Range of values/factory settings	Brief description
129	11020	P-01 Maximum speed	If $P-10 = 0$: $P-02 - 50\text{Hz} - (5 \times P-09)$ If $P-10 > 0$: $P-02 - (5 \times P-10)$	The upper speed limit is in Hz or 1/min (if $P-10 > 0$) Maximum values: 500 Hz or 30000 1/min
130	11021	P-02 Minimum speed	0 – $P-01$	Upper speed limit in Hz or 1/min, see $P-10$
Ramps				
131	11022	P-03 Acceleration ramp	0 – 5 – 600 s	Acceleration ramp time in seconds. The ramp time refers to a setpoint step change of 0 – 50 Hz (1 500 1/min).
132	11023	P-04 Deceleration ramp	0 – 5 – 600 s	Deceleration ramp time in seconds. The ramp time is based on a setpoint step change of 50 Hz (1 500 1/min) – 0 Hz.
133	11024	P-05 Stop mode selection	0 – 3	Defines the delay behavior of the drive for normal operation and power failure. See "Extended parameter description" (→ 71).
134	11025	P-06 Energy-saving function	0 – 1	$P-06 = 1$ activates the function. If active, the function automatically reduces the applied motor voltage for small loads. In this case, the smallest possible motor voltage is 50% of the nominal voltage.
Nominal motor data				
135	11012	P-07 Nominal motor voltage	0 – 230 ²⁾ – 250 V 0 – 400 ¹⁾ – 500 V	Nominal voltage according to motor nameplate. With $P-07 = 0$, voltage compensation is deactivated. See "Extended parameter description" (→ 71).
136	11015	P-08 Nominal motor current	25 – 100% of the frequency inverter output current.	Rated current of the motor according to nameplate. DRN.. motor data specified as factory setting.
137	11009	P-09 Rated motor frequency	25 – 50 – 500 Hz	Nominal frequency of the motor according to nameplate.
138	11026	P-10 Nominal motor speed	0 – 3000 1/min	The slip compensation is activated and all parameters are displayed in 1/min when $P-10 > 0$. See "Extended parameter description" (→ 71).
139	11027	P-11 Additional voltage boost/torque boost	0 – 20% of the max. output voltage (resolution 0.1 %) • Size 1: max. 20% • Size 2: max. 15% • Size 3: max. 10%	Increases the output voltage of the inverter by a scalable value (in case of low speed) to obtain a higher motor torque generation in this speed range. See "Advanced parameter description" (→ 71)
140	11028	P-12 Control signal source	0 – 12	Reserved
141	11029	P-13 – Res.	–	
142	11030	P-14 Access code extended parameters	0 – 9999	

1) 460 V (only American variant)

8.1.2 Advanced parameters

Modbus registers	SBus/CANopen Index	Parameters/description	Range of values/factory settings	Brief description
143	11031	P-15 Digital input function selection	0 – 13	Specifies the functions of the digital inputs. See section "P-15 Binary input function selection" (→ 90).
144	11064	P-16 Analog input 1	0 – 10 V, b 0 – 10 V, 0 – 20 mA t 4 – 20 mA, r 4 – 20 mA t 20 – 4 mA, r 20 – 4 mA	Configures the format of the analog input 1. See "Extended parameter description" (→ 73).
145	11003	P-17 PWM frequency	2 – 4 – 16 kHz ¹⁾	See "Extended parameter description" (→ 73).

1) Depending on rated inverter power

User relay				
146	11050	P-18 User relay selection	0 – 1 – 8	Selects the function of the user relay output. See "Extended parameter description" (→ 80).
147	11051	P-19 Relay switching threshold	0 – 100 – 200% of maximum speed <i>P-01</i> or nominal motor current <i>P-08</i>	Specifies the limit value for <i>P-18</i> and <i>P-25</i> .

Setpoint speeds				
148	11036	P-20 Setpoint speed 1	P-02 – P-01 Default: 0 Hz	Internal setpoint for speed 1 if <i>P-10</i> > 0 Input in 1/min
149	11037	P-21 Setpoint speed 2	P-02 – P-01 Default: 0 Hz	Internal setpoint for speed 2 if <i>P-10</i> > 0 Input in 1/min
150	11038	P-22 Setpoint speed 3	P-02 – P-01 Default: 0 Hz	Internal setpoint for speed 3 if <i>P-10</i> > 0 Input in 1/min
151	11039	P-23 Setpoint speed 4	P-02 – P-01 Default: 0 Hz	Internal setpoint for speed 4 if <i>P-10</i> > 0 Input in 1/min
152	11059	P-24 Deceleration ramp 2	0 – 25 s	Via digital input or in the event of power failure according to <i>P-05</i> .

AO/DO				
153	11046	P-25 Analog output function selection	0 – 8 – 9	Selects the function of the analog output. See "Extended parameter description" (→ 77).

Speed skip function				
154	11045	P-26 Speed skip function frequency range	0 – P-01 [Hz]	Determines the frequency range to be skipped. See "Extended parameter description" (→ 78).
155	11044	P-27 Skip center	P-02 – P-01 Default: 0 Hz	Skip center See "Extended parameter description" (→ 78).

Adjustment of V/f characteristic				
156	11099	P-28 Adjustment of V/f characteristic curve (voltage value)	0 – P-07 [V]	Adjustment of the V/f characteristic curve – voltage value of the new operating point. See "Extended parameter description" (→ 79).
157	11098	P-29 Adjustment of V/f characteristic curve (frequency value)	0 – P-09 [Hz]	Adjustment of the V/f characteristic curve – frequency value of the new operating point. See "Extended parameter description" (→ 79).

Inverter behavior in case of enable/restart				
158	11070	P-30 Restart function for terminal mode	Edge – R, Auto-0 – Auto-5	Defines the inverter behavior with reference to the enable digital input and configures the automatic restart function. See "Extended parameter description" (→ 81).
159	11071	P-31 Restart function for keypad/fieldbus mode	0 – 1 – 7	Defines the inverter enable behavior when controlled via the integrated keypad. See "Extended parameter description" (→ 73).

HVAC functions				
160	11132	P-32 Level 1 Direct current holding function, cyclic duration factor	0 – 25 s	Can also be used for DC braking. Therefore the speed must be defined in <i>P-59</i> . See "Extended parameter description" (→ 83).
	11133	P-32 Level 2 Direct current holding function, operating mode	0 – 2	
161	11060	P-33 Flying start function	0 – 2	Flying start function. See "Extended parameter description" (→ 73).
162	11131	P-34 Brake chopper activation	0 – 2	Setting <i>P-34</i> > 0 activates the integrated brake chopper. P-34 = 1 , activated with software protection (only for BWLT 100 002). An error message is issued when the maximum current is exceeded. P-34 = 2 , activated for other BW with external protection.
163	11065	P-35 Analog input/slave scaling	0 – 100 – 2000%	Scaling factor of analog input and slave speed. See "Extended parameter description" (→ 76).

Fieldbus settings				
164	11105	P-36 Level 1 Fieldbus settings, slave address	0 – 1 – 63	See "Extended parameter description" (→ 76).
	11106	P-36 Level 2 Fieldbus settings, baud rate	0 – 1 – 5	
	11107	P-36 Level 3 Fieldbus settings, Timeout response	0 – 8	

Parameter locking function				
165	11074	P-37 Definition access code	0 – 101 – 9999	Defines the access code for <i>advanced parameter set</i> in <i>P-14</i> .
166	11073	P-38 Locks parameter access	0 – 1	Controls user access to the parameters.
167	11066	P-39 Analog input offset	-500 – 0 – 500%	See "Extended parameter description" (→ 77).
168	11056	P-40 Level 1 Display scaling, source	0 – 2	See "Advanced parameter description" (→ 71).
	11057	P-40 Level 2 Display scaling, scaling factor	0 – 16 000	
169	–	P-41 Thermal motor protection to UL 508C	0 – 1	See "Extended parameter description" (→ 86).

PI controller parameter				
170	11075	P-42 PI controller P gain	0 – 1 – 30	Settings for the integrated PI controller. In factory settings: Actual value source = analog input 2 Setpoint source = Fixed value for 0 – 100% of analog input 2, can be digitally set via <i>P-46</i> If operation ≠ factory settings, see "Extended parameter description" (→ 86).
171	11076	P-43 PI controller Integral time constant	0 – 1 – 30 s	
172	11078	P-44 PI controller Run mode	0 – 1	
173	11079	P-45 Level 1 PI controller input signal, setpoint source selection	0 – 1	
	11080	P-45 Level 2 PI controller input signal, actual value source selection	0 – 5	
174	11081	P-46 PI controller setting of digital setpoint	0 – 100%	
175	11067	P-47 Analog input 2	0 – 10 V, b 0 – 10 V, 0 – 20 mA t4 – 20 mA, r4 – 20 mA t20 – 4 mA, r20 – 4 mA, Ptc – th	Configures the format of the analog input 2. See "Extended parameter description" (→ 86).

PI controller parameter				
176	11061	P-48 Timer for standby mode	0 – 25 s	Activating the timer via <i>P-48</i> > 0 s; with <i>n</i> = 0 1/min and controller enable, the inverter goes to standby mode after the time set in <i>P-48</i> .
177	11087	P-49 PI control difference wake-up level	0 – 100%	See "Extended parameter description" (→ 86).
178	11052	P-50 User relay hysteresis band	0 – 100%	Activation via <i>P-50</i> > 0 Percentage of maximum speed <i>P-01</i> or nominal motor current <i>P-08</i> , depending of settings in <i>P-18</i> . See "Extended parameter description" (→ 86).
Motor control parameters				
179	11089	P-51 Selection of motor control procedure	0 – 1 – 5	At factory setting, the inverter is in V/f control mode. See "Extended parameter description" (→ 86).
180	11091	P-52 Auto tune	0 – 1	<i>P-52</i> = 1 enables auto tune measurement. Manual activation of auto tune measurement. ▲ DANGER! The motor may turn after activation.
181	11091	P-53 Level 1 Vector operation control parameter, gain factor (P component)	0 – 250%	Manual fine-tuning control parameter
	11092	P-53 Level 2 Vector operation control parameter, Integral time constant (I component)	0 – 250 ms	
182	11095	P-54 Current limit	0 – 150 – 175%	Maximum current emitted by the inverter. Percentage of <i>P-08</i>
183	11140	P-55 Motor stator resistance	0 – 655.35 Ω	Manual adjustment of stator resistance value. Assigned automatically by auto tune.
184	11142	P-56 Motor stator inductance d axis (Lsd)	0 – 6553.5 mH	Manual adjustment of Lsd value. Assigned automatically by auto tune.
185	11145	P-57 Motor stator inductance q axis (Lsq)	0 – 6553.5 mH	Manual adjustment of Lsq value. Assigned automatically by auto tune.
186	11134	P-58 Speed of DC braking	0 – <i>P-01</i>	Speed for start of DC braking To activate the DC braking, <i>P-32</i> must be changed. See "Extended parameter description" (→ 86).
187	11135	P-59 Current strength of DC holding function	0 – 20 – 100%	Also for DC braking See "Extended parameter description" (→ 86).
188	11146	P-60 Fire mode speed	0 – 250 Hz	Speed in fire mode. To activate the fire mode, select function 13 in <i>P-15</i> .

8.2 Advanced parameter description

8.2.1 Standard parameters

P-05 stop mode selection

Defines the deceleration behavior of the drive for normal operation and power failure.

Range of values:

0 – 2

In the event of power failure:

- 0: Operation continues
- 1: Motor coasts to a halt
- 2: Rapid stop along *P-24*

Normal stop:

- 0: Stop along ramp *P-04*
- 1: Motor coasts to a halt
- 2: Stop along ramp *P-04*

If *P-05* = 0, the frequency inverter attempts to continue operation in the case of a power failure by reducing the motor speed and using the load as a generator.

P-07 nominal motor voltage

Range of values:

- 0 – **230** – 250 V
- 0 – **400 (460)** → Only American variant) – 500 V

Nominal voltage of the motor according to nameplate. For low-voltage drives, this value is limited to 250 V.

Voltage compensation

P-07 > 0 V: activated

If this function is activated, pulse width modulated output voltage of the frequency inverter is kept constant by variable adjustment of the pulses. This way, negative effects, such as decrease of the input voltage on the line side can be stopped and the motor can maintain its nominal torque. Furthermore, thermal losses at the motor, caused by regenerative energy in brake operation, are reduced.

P-07 = 0 V: deactivated

When the voltage compensation is deactivated, higher thermal losses are generated in the motor during braking operation, and the motor torque can be affected by outer influences, such as dropping of the line voltage. The load on the frequency inverter DC link is reduced by this setting.

P-10 nominal motor speed

Range of values:

0 – 30 000 1/min

- 0: Slip compensation (--- FEHLENDER LINK ---) deactivated, all parameters displayed in Hz
- 1: Slip compensation (--- FEHLENDER LINK ---) activated, all parameters displayed in 1/min

P-11 Additional voltage/boost


Range of values:

0 – 20% of the max. output voltage. Resolution 0.1%

- Size 1: max. 20%
- Size 2: max. 15%
- Size 3: max. 10%

Increases the output voltage of the frequency inverter by a scalable value (in case of low speed) to obtain a higher motor torque generation in this speed range.

Vector operation ($P51 \neq 1$): $P-11$ is automatically filled by the auto tune process, if one of the vector control modes was selected in $P-51$.



6353342859

A motor with forced cooling fan must be used for continuous duty at low speeds.

P-12 control signal source

Range of values:

0 – 11

0	Terminal control
1	Control via keypad (only forward)
2	Control via keypad (to toggle between forward/reverse, press the <Start> key)
3	SBus network control with internal acceleration/deceleration ramps
4	SBus network control with adjusted acceleration/deceleration ramp via bus.
5	Modbus RTU network control with internal acceleration/deceleration ramps
6	Modbus RTU network control with adjusted acceleration/deceleration ramp via bus.
7	CANopen network control with internal acceleration/deceleration ramps
8	CANopen network control with adjusted acceleration/deceleration ramp via bus
9	Standard PI controller mode
10	Advanced PI controller mode
11	Master-slave operation

8.2.2 PWM

P-17 PWM switching frequency

Specifies the pulse width modulated switching frequency. A higher switching frequency means less motor noise, but also higher losses in the output stage. The following table shows the PWM switching frequency values in dependency of the performance class.

Input voltage V	Performance class kW	PWM factory settings kHz	min. PWM kHz	max. PWM kHz
1 × 110	0.37 – 1.1	4	2	16
1 × 230	0.37 – 2.2			16
3 × 230				
1 × 230	4			12
3 × 230				
3 × 400	0.75 – 4			16
3 × 400	5.5 – 7.5			12
3 × 400	11			8

8.2.3 Analog inputs

P-16, P-48 analog input

(Description also applies to analog input 2)

Range of values:

Display		Range of values	Explanation
U	0 – 10	0 – 10 V	Unipolar mode (voltage input)
b	0 – 10	-10 – 10 V	Bipolar mode (voltage input)
A	0 – 20	0 – 20 mA	Unipolar mode (current input)
t	4 – 20	4 – 20 mA	Unipolar mode (current input)
r	4 – 20	4 – 20 mA	Unipolar mode (current input)
t	20 – 4	4 – 20 mA (inv.)	Inverted unipolar mode (current input)
r	20 – 4	4 – 20 mA (inv.)	Inverted unipolar mode (current input)
–	Ptc-th (only <i>P-48</i>)	–	Select the setting for operation of PTC motor thermistor


b = Bipolar mode

t = Frequency inverter switches off if signal is revoked when frequency inverter is enabled.

r = Indicates that the inverter moves along the ramp to the speed set in *P-20*.

Bipolar mode

This function allows for infinitely variable speeds in the speed range of -100% to +100% via *P-01* without changing the digital input. As an alternative, a curve toward [B] can be realized.



12804908811

Curve A

When using an analog input signal with voltage range -10 V to +10 V (bipolar mode)

P-16 = 0 – 10b

Curve B

Can be operated according to this curve with the following settings in the frequency inverter:


P-16 = 0 – 10 V (factory settings)

P-35 = 200%

P-39 = 50%

P-35 Analog input/slave scaling

Range of values: See 0 – 100 – 2000

Analog input scaling

6355552139

Scaling of slave, if $P-12 = 11$

$$P-35 = (n_{\text{slave}} / n_{\text{master}}) \times 100\%$$

Example

Master speed = 1500 1/min

Desired slave speed = 750 1/min

$$P-35 = 750 / 1500 \times 100\% = 50$$


The slave speed is limited by *P-01* and *P-02*

P-39 analog input offset

Range of values:

-500 – 0 – 500%

Analog input offset, resolution 0.1%.



6355554571

8.2.4 Analog output

P-25 analog output function selection

Range of values:

0 – 8 – 10

0	Frequency inverter is enabled (digital)
1	Frequency inverter is ready for operation (digital)
2	Motor at setpoint speed (digital)
3	Frequency inverter is in fault status (digital)
4	Motor speed \geq limit value <i>P-19</i> (digital)
5	Motor current \geq limit value <i>P-19</i> (digital)
6	Motor speed $<$ limit value <i>P-19</i> (digital)
7	Motor current $<$ limit value <i>P-19</i> (digital)
8	Motor speed (analog)
9	Motor current (analog)
10	Motor power (analog)

Setting as digital output

Deactivated: 0 V

Activated: +24 V (20 mA limit value)

Setting as analog output


- Selection 8: Motor speed signal range
0 – 10 V = 0 – 100% of *P-01*
- Selection 9: Motor current signal range
0 – 10 V = 0 – 200% of *P-08*

8.2.5 Speed skip function**P-26, P-27 speed skip function**

Range of values:

0 – *P-01*

In some applications, mechanical resonance vibrations may occur in certain speed ranges. This may have a negative effect on the machine behavior. The speed skip function can be used to skip the interfering speed range. The drive speed performs the depicted hysteresis with the ramps specified in *P-03* and *P-04*.



9007205610286091

P-26 Describes the extend of the frequency range*P-27* Describes the center of the frequency range**Example:**

Skipping the speed range 27 Hz – 37 Hz

Start frequency = 27 Hz; end frequency = 37 Hz

P-26 = 37 Hz - 27 Hz = **10 Hz***P-27* = Start frequency + *P-26*/2 = 27 Hz + 5 Hz = **32 Hz**


If the setpoint speed is within the skipped frequency range, the input speed remains on the upper or lower limit of the frequency range, depending on the direction of acceleration.

8.2.6 Adjustment of V/f characteristic

P-28, P-29 V/f characteristic curve adjustment

In this function, an additional operating point of the frequency inverter V/f characteristic can be created.

- If this operating point is below the standard characteristic (operating point 1), the motor consumes less energy for all speeds below the nominal working point. But in this case the motor has a lower torque. This setting is suitable for pump and fan applications, among others.
- If the operating point is above the standard characteristic (operating point 2), the motor generates a higher torque for all speeds below the nominal working point. But this results in the motor generating more heat. This setting is suitable when a motor instability occurs in certain frequencies. In this case, increase or reduce the voltage (P-28) at the instable speed (P-29).



12265183371

P-07 = Nominal motor voltage

P-09 = Rated motor frequency

P-28 = Voltage value of adjustment of the V/f characteristic curve

P-29 = Frequency value of adjustment of the V/f characteristic curve

Example:

Operating point 1 = $P-28_1/P-29$

Operating point 2 = $P-28_2/P-29$

8.2.7 User relay

P-18 selection of user relay output

Range of values:

0 – 1 – 7


0	Frequency inverter is enabled. Select this function to control the electromechanical motor holding brake. For brake control installation, see chapter "Installation" (→ 23).
1	Frequency inverter is ready for operation
2	Motor at setpoint speed
3	Frequency inverter in fault status
4	Motor speed \geq limit value <i>P-19</i>
5	Motor current \geq limit value <i>P-19</i>
6	Motor speed $<$ limit value <i>P-19</i>
7	Motor current $<$ limit value <i>P-19</i>
8	Analog input 2 $>$ limit value <i>P-19</i>

The switching threshold of the limit value is defined in *P-19*.

The relay contact is designed as NO contact.

P-51 User relay hysteresis band

Range of values: 0 – 100%



9007211969771275

Upper limit: Speed defined by *P-19*

Lower limit: Upper limit minus value defined in *P-51*

Application example:

P-01 = 50 Hz

P-18 = 4 → „Relay closes when inverter speed \geq value in *P-19*“

P-19 = 50% = 25 Hz

The actual motor speed fluctuates around the setpoint 25 Hz by ± 2 Hz (value is *P-19*). Unwanted instable relay states occur ("clicking"). To avoid this, you can set *P-51* = 5% = 2.5 Hz. The speed fluctuations are now within the hysteresis, the relay maintains its state.

8.2.8 Inverter behavior in case of enable/restart

P-30 terminal mode restart function

Defines the frequency inverter behavior with regard to the enable digital input and configures the automatic restart function.

Range of values:

Edge-R, **Auto-0**, Auto-1 – Auto-5

- **Edge-R:**

After activation or resetting of an error, the frequency inverter does not start automatically, even if an enable signal is still present at the relevant digital input. To start the frequency inverter after activation or resetting, the signal must first be deleted (open switch) and then reset (close switch).

- **Auto-0:**

After activation or resetting, the frequency inverter starts automatically if an enable signal is still present at the relevant digital input.

- **Auto-1 – Auto-5:**

Following an error shutdown (trip), the frequency inverter makes up to 5 attempts to restart at intervals of 20 seconds. To reset the counter, the frequency inverter must be de-energized. The number of attempted restarts is counted. If the frequency inverter is unable to start the drive with the final attempt, a permanent error shutdown occurs, which can only be reset by pressing the "Reset" key.

P-31 Restart function for keypad/fieldbus

Defines the frequency inverter enable behavior when controlled via the integrated keypad or fieldbus.

Range of values:

0 – 1 – 7

Mode	Designation	Explanation
0	Minimum speed	Press the <Start> key to start.
1	Most recently used speed	Press the <Start> key to start.
2	Minimum speed (Auto run)	To start the hardware enable via digital inputs.
3	Most recently used speed (auto run)	To start the hardware enable via digital inputs.
4	Current speed	Press the <Start> key to start.
5	Preset speed 4	Press the <Start> key to start.
6	Current speed (Auto run)	To start the hardware enable or digital inputs.
7	Preset speed 4 (Auto run)	To start the hardware enable or digital inputs.

8.2.9 HVAC functions

DC braking and holding function (P-32, P-59, P-60)


Direct current injection into the motor winding enables a homogenous magnetic field to be generated during the time set in *P-32*. When an external force applies torque to the rotor, the magnetic field generates a braking torque.

The direct current braking and holding function allow for the following drive-specific tasks:

Responsibilities	Task	Parameters
HVAC	Fan rotor restart inhibit due to air flow.	P-32, P-59
HVAC, materials handling technology	DC braking from a defined speed with subsequent holding brake (max. 25 s in total)	P-32, P-58, P-59
HVAC	Defined start of speed "0" for a fan rotor in the air flow.	P-32, P-59

Application example

DC holding function with DC braking



16872908683

- t_1 = Time of DC braking
- t_2 = Time of DC holding braking
- t_DC = Time of DC holding function [P-32]
- n_B = Start speed of DC braking [P-59]
- I_B = Injected direct current [P-60]

P-32 DC hold function

Level	Program no.	Range of values	Default value	Function
1	–	0 – 25 s	0 s	Direct current injection, time Direct current injection activated, if P-32/1 > 0 s
2	0	0 – 2	0	Direct current injection at STOP
	1			Direct current injection at START
	2			Direct current injection at STOP and START

22511067/EN – 04/2016

P-59 DC braking speed

Range of values: **0** – P-01

Speed for start of DC braking

To activate the DC braking, *P-32/1* must be set to > 0 s.

P-60 Current strength of DC holding function

Range of values: 0 – 100%

Value in [%] of *P-08*. Determined the strength of the direct current injection.

P-33 flying start function

Range of values: **0** – 2

In case of an activated flying start function, the frequency inverter starts the motor control based on the latest measured rotor speed. If the rotor is at speed "0", startup may have a brief delay.

Setting P-33	Description
0	Flying start function disabled
1	Flying start function enabled
2	Flying start function only activated if the following conditions are met: <ul style="list-style-type: none"> • Switch off with error • Voltage drop • Freewheel stop

8.2.10 Fieldbus settings

P-36 fieldbus settings

P-36 is distinguished into levels in the frequency inverter keypad. Press the <Navigate> button to get to the next level.

The frequency inverter display shows program numbers on level 2 of *P-36*. Depending on the setting in *P-12*, different values are valid for these numbers. The following table shows the assignment of program number and related value depending on *P-12*.

Level	Program no.	Value	
		SBus (<i>P-12</i> = 3/4) CAN (<i>P-12</i> = 5/6)	Modbus RTU (<i>P-12</i> = 7/8)
1 – Slave address		1 – 63	1 – 63
2 – Baud rate	0	500 kb/s	9.6 kb/s
	1	500 kb/s	115.2 kb/s
	2	125 kb/s	19.2 kb/s
	3	250 kb/s	38.4 kb/s
	4	500 kb/s	57.6 kb/s
	5	1 Mb/s	76.8 kb/s
3 – Timeout reaction in ms	0	0 (no error)	
	1	t 30	
	2	t 100	
	3	t 1000	
	4	t 3000	
	5	r 30	
	6	r 100	
	7	r 1000	
	8	r 3000	

The setting "0" deactivates the communication switch-off.

t_x: The frequency inverter immediately switches off when the time **x** [ms] is exceeded.

r_x: The motor is stopped along a ramp when the time **x** [ms] is exceeded.

8.2.11 Display scaling

P-40 Display scaling

P-40 is distinguished into levels in the frequency inverter keypad. Press the <Navigate> button to get to the next level.

Level	Program no.	Value
1 – Source	0	Motor speed
	1	Motor current
	2	Value of analog input 2
2 – Factor	–	0 – 16000

Appears on the operating state display (cXXX) in real time.

8.2.12 Thermal motor protection to UL508C

P-41 thermal motor protection according to UL508C

- 0/deactivated
- 1/activated

The frequency inverters come equipped with a thermal motor protection function according to NEC (National Electrical Code) to protect the motor from overload. In an internal memory, the motor current is accumulated over time.

The frequency inverter goes to fault state as soon as the thermal limit is exceeded (I.t-trP).

Once the output current of the frequency inverter is less than the set rated motor current, the internal memory is decremented depending on the output current.

When *P-41* is disabled, the thermal overload memory is reset when switching power off and on again.

When *P-41* is enabled, the memory is maintained even after power off and on again.

8.2.13 PI controller

P-42 PI proportional gain

Range of values: 0 – 1 – 30

Controller proportional gain. Higher values result in a greater change of the frequency inverter output frequency as response to minor changes of the feedback signal. If the value is too high, it can cause instability.

P-43 PI integrated time constant

Range of values: 0 – 1 – 30 s

Higher values result in a damped A too high value can lead to unwanted inertia of the control system.

P-44 PI controller operating mode

Range of values: 0 – 1

Setting P-44	Response of speed to negative control difference (actual value decreases)
0: Standard	Rising
1: Inverted	Falling

P-45 Controller input signal

Range of values: 0 – 1

Level	Description	Program no.	Source
1	Setpoint source	0	Digital = value in P-46
		1	Analog = analog input 1
2	Actual value source	0	Analog input 2
		1	Analog input 1
		2	Motor current, P-08
		3	DC link voltage
		4	Analog input 1 – analog input 2 Comparison of 2 analog actual values. The value difference is compared to the setpoint. Connect the actual values to analog input 1 and analog input 2. P-45/1 must be set to "0".
		5	Maximum value (analog input 1; analog input 2) Comparison of the values from both analog inputs. The maximum value is used as PI actual value.

P-46 Setting a digital setpoint

Range of values: 0 – 100% of the feedback signal

Example: Feedback signal 0 – 10 V, P – 46 = 50% = 5 V

P-49 PI control difference

Range of values: 0 – 100%

When the inverter is in standby during PI controller mode, the selected feedback signal (actual value of the controlled system) must fall below this threshold defined in P-49 before the inverter returns to normal operation.

8.2.14 Motor control parameter

P-51 Selection of motor control procedure

Range of values: 0 – 1 – 5

Settings in P-51	Motor control mode	Motor types
0	VFC-ASM speed control	Asynchronous machines
1	V/f control	Asynchronous machines
2	VFC-PM speed control	Permanent-field synchronous machine
3	BLDC speed control	Brushless DC motors
4	Sync. Magnetic reluctance motor control	Synchronous reluctance motors
5	LSPM motor control	SEW LSPM motors

Annotations

0/VFC speed control

Vector speed control for induction motors with calculated rotor speed feedback control. Field oriented control algorithms are used for motor speed control. As the calculated rotor speed is used to internally, virtually close the speed loop, this control mode provides a closed loop control without physical encoder. With a properly tuned speed controller, the static speed change is usually better than 1%. For optimal control, auto tune (P-52) can be carried out prior to first operation.

1/Extended V/f controller (default)

During V/f control mode, the motor speed is set by linear varying of voltage and frequency at the inverter output. This setting is sufficient for most applications. If a better performance is required in regard of control mode, torque stability and speed range, the VFC control mode should be used.

Slip compensation

The MOVITRAC® LTE-B frequency inverter uses an extended V/f control. This means, with active slip compensation ($P-10 > 0$) the load-dependent speed drop is compensated by the frequency inverter increasing the output frequency f_A in the relevant operating point by the load-dependently calculated component Δ_f .

2/VFC-PM Speed control

Analog characteristics of the VFC speed control, but with PM speed control the machine model of a permanent-field synchronous motor is used for calculating the initial size.

3/BLDC Speed control

Analog characteristics of the VFC speed control, but with BLDC speed control the machine model of a "brushless DC motor" (BLDC motor) is used for calculating the initial size. The resulting current output curve differentiates compared to the PM motor control.

4/Sync Reluctance motor control

Analog characteristics of the VFC speed control, but with synchronous magnetic reluctance speed control the machine model of a synchronous magnetic reluctance motor is used for calculating the initial size.

5/LSPM motor control

Use this setting when a Line Start Permanent Magnet motor (LSPM motor) by SEW-EURODRIVE is connected to the MOVITRAC® LTE-B inverter.

P-54 Vector operation gain factor




NOTICE

Possible damage to the frequency inverter.

The following parameters are used internally by the inverter to provide for optimum motor control. Incorrect settings of the parameters can result in poor performance and unexpected behavior of the motor. Adjustments should be made only by experienced users who fully understand the functions of these parameters.

Equivalent wiring diagram for AC motors.



7372489995

P-56 Motor stator resistance [RS]

Setting range: depends on the motor (Ω)

The stator resistance value is the ohmic phase-phase resistance of the copper winding. This value can be determined and set automatically during auto tune.

Instead, you can enter this value manually.

P-57 Motor stator inductance of d-axis (Lsd)

Range of values: 0 – 6553.5 mH

Motor stator inductance (Lsd)

Setting range: depends on the motor (H)

For induction motors: Phase stator inductance value

For permanent magnet motors: Phase d-axis stator inductance in Henry

P-58 Motor stator inductance of q-axis (Lsq)

Range of values: 0 – 6553.5 mH

Motor stator inductance (Lsq) – only for PM motors

Setting range: depends on the motor (H)

For permanent magnet motors: Phase q-axis stator inductance in Henry

8.3 P-15 Binary input function selection

The functions of the digital inputs in the frequency inverter can be programmed. You can select the functions required for your application.

The following tables show the functions of the digital inputs depending on the value of parameter *P-12* and *P-15*.

8.3.1 Terminal mode



When parameter *P-12* = 0 (terminal mode), the following table applies:

P-15 Selection	Digital input 1	Digital input 2	Digital input 3 / analog input 2	Digital input 4 / analog input 1	Comments
0	0: Stop/controller inhibit 1: Enable/start	0: CW rotation 1: CCW rotation	0: (0 V) Analog speed value reference 1: (10 – 24 V) Preset speed 1	Speed reference	–
1	0: Stop/controller inhibit 1: Enable/start	0: Analog speed value reference 1: Preset speed 1 or 2	0: (0 V) Preset speed 1 1: (10 – 24 V) Preset speed 1	Speed reference	–
2	0: Stop/controller inhibit 1: Enable/start	0: Released 1: Applied	0: (0 V) released 1: (10 – 24 V) applied	0: Preset speed 1 – 4 1: Max. speed (P-01)	Preset speed 1 Preset speed 2 Preset speed 3 Preset speed 4
3	0: Stop/controller inhibit 1: Enable/start	0: Analog speed value reference 1: Preset speed 1	0: (0 V) Disconnection TF/TH 1: (10 – 24 V) Motor temperature OK	Speed reference	Connect external temperature sensor to digital input 3.
4	0: Stop/controller inhibit 1: Enable/start	0: CW rotation 1: CCW rotation	0: (0 V) Analog speed value reference 1: (10 – 24 V) Preset speed 1	Speed reference	–
5	0: CW rotation stop 1: CW rotation To stop the motor using the rapid stop ramp, connect the digital inputs 1 and 2 with each other.	0: CCW rotation stop 1: CCW rotation	0: (0 V) Analog speed value reference 1: (10 – 24 V) Preset speed 1	Speed reference	Integrated rapid stop function via digital inputs 1 and 2.
6	0: Stop/controller inhibit 1: Enable/start	0: CW rotation 1: CCW rotation	0: (0 V) Disconnection TF/TH 1: (10 – 24 V) Motor temperature OK	Speed reference	Connect external temperature sensor to digital input 3.
7	0: CW rotation stop 1: CW rotation To stop the motor using the rapid stop ramp, connect the digital inputs 1 and 2 with each other.	0: CCW rotation stop 1: CCW rotation	0: (0 V) Disconnection TF/TH 1: (10 – 24 V) Motor temperature OK	Speed reference	Integrated rapid stop function via digital inputs 1 and 2. Connect external temperature sensor to digital input 3.
8	0: Stop/controller inhibit 1: Enable/start	0: CW rotation 1: CCW rotation	0: (0 V) released 1: (10 – 24 V) applied 0: (0 V) released 1: (10 – 24 V) applied	0: Released 0: Released 1: Applied 1: Applied	Preset speed 1 Preset speed 2 Preset speed 3 Preset speed 4
9	0: CW rotation stop 1: CW rotation	0: CCW rotation stop 1: CCW rotation	0: (0 V) released 1: (10 – 24 V) applied 0: (0 V) released 1: (10 – 24 V) applied	0: Released 0: Released 1: Applied 1: Applied	Preset speed 1 Preset speed 2 Preset speed 3 Preset speed 4
10	Button function, NO contact Positive edge: Enable	Button function, NC contact Negative edge: Stop	0: (0 V) Analog speed value reference 1: (10 – 24 V) Preset speed 1	Speed reference	Function for operation with buttons (pulse control)

P-15 Selection	Digital input 1	Digital input 2	Digital input 3 / analog input 2	Function	Digital input 4 / analog input 1	Comments
11	0	1	1 (10 – 24 V)	CCW rotation	Speed reference	Function for operation with buttons (pulse control)
	0	0	1 (10 – 24 V)	Backward stop		
	1	1	0 (0 V)	CW rotation		
	1	0	0 (0 V)	CW rotation stop		
	1	0	1 (10 – 24 V)	Rapid stop along <i>P-24</i>		
P-15 Selection	Digital input 1	Digital input 2	Function	Digital input 3	Analog input	Comments
12	0	0	Stop/controller inhibit	0 : (0 V) Analog speed value reference 1 : (10 – 24 V) Preset speed 1	Speed reference	–
	1	0	Stop with ramp 1 (<i>P-04</i>)			
	0	1	Stop with ramp 2 (<i>P-24</i>)			
	1	1	Enable/start			
P-15 Selection	Digital input 1	Digital input 2	Digital input 3 / analog input 2	Digital input 4 / analog input 1		Comments
13	0 : Stop/controller inhibit 1 : Enable/start	0 : Preset speed 1 : Analog input 1	0 : (0 V) Fire mode 1 : (10 – 24 V) Normal operation	Speed reference		Fire mode function

8.3.2 Keypad mode

When parameter *P-12* = 1 or 2 (keypad mode), the following table applies.

P-15	Digital input 1	Digital input 2	Digital input 3 / analog input 2	Digital input 4 / analog input 1	Comments	Key 5 	Key 6 
0, 1, 5, 8-12	0: Stop/controller inhibit 1: Enable/start	0: No function 1: Speed up When digital input 2 and 3 are disabled together, the START button is ignored.	0 (0 V) no function 1 (10 – 24 V) speed down	0 (0 V): CW rotation 1 (10 – 24 V): CCW rotation	Notice: When digital input 2 and 3 are disabled together the motor may startup immediately.	Increase speed	Reduce speed
1	0: Stop/ controller enable 1: Enable/start	No function	Speed reference ¹⁾	No function	Speed reference, can be selected via <i>P-45</i>		
2	0: Stop/controller inhibit 1: Enable/start	0: No function 1: Speed up When digital input 2 and 3 are disabled together, the START button is ignored.	0: (0 V) no function 1: (10 – 24 V) speed down	0: (0 V) Speed reference keypad 1: (10 – 24 V) Fixed setpoint speed 1	Notice: When digital input 2 and 3 are disabled together the motor may startup immediately.	Increase speed	Reduce speed
3	0: Stop/controller inhibit 1: Enable/start	0: No function 1: Speed up	0: (0 V) Disconnection TF/TH 1: (10 – 24 V) Motor temperature OK	0: (0 V) no function 1: (10 – 24 V) speed down	Connect external temperature sensor to digital input 3. Notice: When digital input 2 and 4 are disabled together, the START button is ignored. This may result in immediate motor startup.	Increase speed	Reduce speed
4	0: Stop/controller inhibit 1: Enable/start	0: No function 1: Speed up	0: (0 V) Speed reference keypad 1: (10 – 24 V) Analog input speed reference	Speed reference	–	Increase speed	Reduce speed
6	0: Stop/controller inhibit 1: Enable/start	0: CW rotation 1: CCW rotation	0: (0 V) Disconnection TF/TH 1: (10 – 24 V) Motor temperature OK	0 (0 V): Speed reference keypad 1 (10 – 24 V): Fixed setpoint speed 1	Connect external temperature sensor to digital input 3.	Increase speed	Reduce speed
7	0: Stop/controller inhibit 1: Enable/start To stop the motor using the rapid stop ramp, connect the digital inputs 1 and 2 with each other.	0: Stop 1: CW rotation	0: (0 V) Disconnection TF/TH 1: (10 – 24 V) Motor temperature OK	0 (0 V): Speed reference keypad 1 (10 – 24 V): Fixed setpoint speed 1	Integrated rapid stop function via digital inputs 1 and 2. Connect external temperature sensor to digital input 3.	Increase speed	Reduce speed
13	0: Stop/ controller enable 1: Enable/start	0: Activate velocity control fixed setpoint 1: Speed reference keypad	0: (0 V) Fire mode 1: (10 – 24 V) Normal operation	0: (0 V) Fixed setpoint speed 1 1: (10 – 24 V) Fixed setpoint speed 2	Fire mode function	Increase speed	Reduce speed

1) in factory setting analog input 2

8.3.3 SBus, CANopen and slave control mode

When parameter *P-12* = 3 or 4 (SBus control mode), the following table applies:

P-15	Digital input 1	Digital input 2	Digital input 3 / analog input 2	Digital input 4 / analog input 1	Comments
0, 2, 4, 8 – 12	0: Controller inhibit 1: Enable	No effect	No effect	No effect	Enable via DI1 and gateway/master ¹⁾ .

P-15	Digital input 1	Digital input 2	Digital input 3 / analog input 2	Digital input 4 / analog input 1	Comments
1	0: Controller inhibit 1: Enable	No function	Speed reference ²⁾	No effect	Enable via DI1 and gateway/master ¹⁾ Speed reference, can be selected via P-45
3	0: Controller inhibit 1: Enable	0: Master speed reference 1: Preset speed 1	0: (0 V) Disconnection TF/TH 1: (10 – 24 V) Motor temperature OK	No effect	Enable via DI1 and gateway/master ¹⁾ Connect external temperature sensor to digital input 3.
5	0: Controller inhibit 1: Start	0: Master speed reference 1: Preset speed	0: (0 V) Preset speed 1 1: (10 – 24 V) Preset speed	No effect	When DI2 = 0, enable via DI1 and gateway/master
6	0: Controller inhibit 1: Enable	0: Master speed reference 1: Analog input 1 speed reference	0: (0 V) Disconnection TF/TH 1: (10 – 24 V) Motor temperature OK	Speed reference	Enable via DI1 and gateway/master ¹⁾ Connect external temperature sensor to digital input 3.
7	0: Controller inhibit 1: Enable	0: Master speed reference 1: Speed reference on keypad	0: (0 V) Disconnection TF/TH 1: (10 – 24 V) Motor temperature OK	No effect	Enable via DI1 and gateway/master ¹⁾ Connect external temperature sensor to digital input 3.
13	0: Controller inhibit 1: Enable	0: Velocity control fixed setpoint activated 1: Master speed reference	0: (0 V) Fire mode 1: (10 – 24 V) Normal operation	0: (0 V) Preset speed 1 1: (10 – 24 V) Pre-set speed 2	Enable DI1 and gateway/master ¹⁾ Fire mode function

1) If P-31 = 2, 3, 6 or 7, enable only via DI1 (does not apply to Sbus)

2) in factory setting analog input 2

8.3.4 Modbus RTU control mode

When parameter P-12 = 5 or 6 (Modbus RTU control mode), the following table applies:

P-15	Digital input 1	Digital input 2	Digital input 3 / analog input 2	Digital input 4 / analog input 1	Comments
0, 2, 4, 8 – 12	0: Controller inhibit 1: Enable	No effect	No effect	No effect	Enable via DI1 and Modbus master ¹⁾ .
1	0: Controller inhibit 1: Enable	No effect	Speed reference ²⁾	No effect	Enable via DI1 and Modbus master ¹⁾ Speed reference, can be selected via P-45
3	0: Controller inhibit 1: Enable	0: Master speed reference 1: Preset speed 1	0: (0 V) Disconnection TF/TH 1: (10 – 24 V) Motor temperature OK	No effect	Enable via DI1 and Modbus master ¹⁾ Connect external temperature sensor to digital input 3.
5	0: Controller inhibit 1: Enable	0: Master speed reference 1: Preset speed	0: (0 V) Preset speed 1 1: (10 – 24 V) Preset speed 2	No effect	When DI2 = 0, enable via DI1 and gateway. When DI2 = 1, enable only via DI1.
6	0: Controller inhibit 1: Enable	0: Master speed reference 1: Analog input speed reference	0: (0 V) Disconnection TF/TH 1: (10 – 24 V) Motor temperature OK	Speed reference	When DI2 = 0, enable via DI1 and gateway When DI2 = 1, enable only via DI1 Connect external temperature sensor to digital input 3.
7	0: Controller inhibit 1: Enable	0: Master speed reference 1: Speed reference on keypad	0: (0 V) Disconnection TF/TH 1: (10 – 24 V) Motor temperature OK	No effect	
13	0: Controller inhibit 1: Enable	0: Preset speed 1: Master speed reference	0: (0 V) Preset speed 1 1: (10 – 24 V) Normal operation	0: (0 V) Preset speed 1 1: (10 – 24 V) Pre-set speed 2	Enable via DI1 and Modbus master ¹⁾ Fire mode function

1) If P-31 = 2, 3, 6 or 7, enable only via DI1

2) in factory setting analog input

8.3.5 PI control mode

P-15	Digital input 1	Digital input 2	Digital input 3 / analog input 2	Digital input 4 / analog input 1	Comments
0, 2, 7 – 12	0: Controller inhibit 1: Enable	0: PI controller mode 1: Preset speed 1	Input actual value	No effect	Can be used with $P-45 = 1$.
1	0: Controller inhibit 1: Enable	0: PI controller mode 1: Preset speed 1	Input actual value	Input setpoint value	
3	0: Controller inhibit 1: Enable	0: PI controller mode 1: Preset speed 1	0: (0 V) Disconnection TF/TH 1: (10 – 24 V) Motor temperature OK	Input actual value	Connect external temperature sensor to digital input 3.
4	Button function NO contact Positive edge: Enable	Button function NC contact Negative edge: Stop	No effect	No effect	Functions when internal actual source $P-45/2 > 0$
5	Button function NO contact Positive edge: Enable	Button function NC contact Negative edge: Stop	0: (0 V) PI controller mode 1: (10 – 24 V) Preset speed 1	No effect	
6	Button function NO contact Positive edge: Enable	Button function NC contact Negative edge: Stop	0: (0 V) Disconnection TF/TH 1: (10 – 24 V) Motor temperature	No effect	Connect external temperature sensor to digital input 3. Function when internal actual source $P-45/2 > 0$
7	0: Controller inhibit 1: Enable	0: PI controller mode 1: Preset speed 1	0: (0 V) Disconnection TF/TH 1: (10 – 24 V) Motor temperature OK	Input actual value	Connect external temperature sensor to digital input 3.
8	0: Controller inhibit 1: Enable	0: CW rotation 1: CCW rotation	Input actual value	No effect	
13	0: Controller inhibit 1: Enable	0: Preset speed 1 1: PI controller mode	0: (0 V) Fire mode 1: (10 – 24 V) Normal operation	Input actual value	Fire mode function

8.4 Parameters for monitoring operating data in real time (read only)

You can monitor the internal operating data of the inverter using parameter group *P00*. These parameters cannot be changed.

8.4.1 Access to parameter group 0

Access to parameter group 0

When *P-14* = *P-37* (factory set to 101), all parameters are visible.

You can switch to *P-00* by pressing the <Navigate> key. "P00-z" is displayed, "z" represents the second number within *P-00* (meaning 1 – 50). You can then go the required parameter *P-00*.

Pressing the <Navigate> key again then displays the value of this specific parameter group "0".

The various values of parameters with several values (such as software ID), can be displayed by pressing the <Up>/<Down> keys.

To go to the next higher level, quickly press the <Navigate> key. By pressing the <Navigate> key quickly again (without pressing the <Up>/<Down> keys), the display shows the next higher level (main level of the parameters, that is *P-00*).

When you are on the lower level (e.g. *P00-05*) and press the key <UP>/<DOWN> to change the directory *P-00*, this parameter value is displayed by pressing the key <Navigate>.

8.4.2 Description of parameter group 0

Parameters	CANopen/Sbus index	Parameters/description	Display range	Explanation
20	11210	P00-01 value of analog input 1	0 – 100%	100% = max. input current/voltage
21	11211	P00-02 value of analog input 2	0 – 100 %	100% = max. input current/voltage
22, 40	11213	P00-03 input speed – set-point	P-01 (min) – P-01 (max)	Speed display in Hz when <i>P-10</i> = 0, else in 1/min.
11	11212	P00-04 Status of digital inputs	Binary value	
39	11232	P00-05 Internal temperature of inverter	-25 °C – 125 °C	
	11288	P00-06 DC link voltage ripple	0 – 1000 V	
43	11270	P00-07 Present motor voltage	AC 0 – 600 V	Inverter output voltage r.m.s. value
23	11220	P00-08 Current DC link voltage	DC 0 – 1000 V	
24	11221	P00-09 Heat sink temperature	-20 °C – 100 °C	
25, 26	11296 – 11297	P00-10 Operating hours counter	0 – 99999 h	Value is permanently saved. Factory setting does not apply.
–	11298 – 11299	P00-11 Operating time since the last fault 1	0 – 99999 h	Operating time since the last fault (TRIP) or disconnection (mains off). The timer is reset when another fault is triggered or the device is disconnected gain.
–	11300 – 11301	P00-12 Operating time since the last fault 2	0 – 99999 h	Operating time since the last fault (TRIP) The timer is reset when another fault is triggered or the device is disconnected gain.

Parameters	CANopen/Sbus index	Parameters/description	Display range	Explanation
28	11302 – 11303	P00-13 Operating time since the last activation	0 – 99999 h	Displays the operating time of an enable interval. The timer is reset at each following enable
–	11350	P00-14 Current PWM switching frequency	2 – 16 kHz	The value may be below the settings in <i>P-17</i> , as it is automatically reduced in case of thermal overload
–	11305 – 11313	P00-15 DC link voltage protocol	0 – 1000 V	Displays the last 8 values prior to the switch off with error
–	11322 – 11329	P00-16 Heat sink temperature protocol	-20 °C – 120 °C	Displays the last 8 values prior to the switch off with error
–	11330 – 11337	P00-17 Motor current protocol	0 – 2 × I _N	Displays the last 8 values prior to the switch off with error
15, 16	11247 – 11250	P00-18 Software ID, I/O and motor control	e.g. „1.00“, 47 AE	Left value= I/O processor, right value = motor control
34 – 37	11251 – 11254	P00-19 Inverter serial number	A/B/C A= 0 – 999999, B = 0 – 99 C = 0 – 99999	Unique serial number of the inverter
12 – 14, 17	11255	P00-20 Inverter ID	e.g. LTE-B+ 1ph/0.37/2.00	Type/performance/FW version
–	11256 – 11258	P00-21 Incoming process data (CANopen, Sbus)	–	PE1 – PE3, gateway -> inverter
–	11259 – 11261	P00-22 Outgoing process data (CANopen, Sbus)	–	PA1 – PA3, inverter -> gateway
–	11289 – 11290	P00-23 Total time of heat sink temperature > 85 °C	0 – 65000 h	Time during which a temperature of > 85 °C was measured at the heat sink
–	11237 – 11238	P00-24 Total time of internal inverter temperature > 80 °C	0 – 65000 h	Time during which the inverter was operated at > 80 °C
–	11291	P00-25 Rotor speed (calculated via motor model)	-P01 – P01	Applies only to vector mode
32, 33	11292 – 11293	P00-26 kWh counter/MWh counter	xxxx	
–	11304 – 11305	P00-27 Runtime of inverter fan	0 - 65000	Runtime clock for internal fan
–	11272 – 11281	P00-28 Error log	xxxx	Shows the last 4 errors
–	11219	P00-29 PI controller output	0 – 100 %	PI output
–	11314 – 11321	P00-30 DC link voltage ripple protocol	0 – 1000 V	Displays the last 8 values prior to the switch off with error
–	11282 – 11283	P00-31 Magnetization current und torque current I _d /I _q	0 – 100.0 A	Current specification in A _{rms} Using the keypad: Use the <UP> button to display the I _q
–	11239 – 11246	P00-32 Protocol of internal temperature of inverter	-25 °C – 125 °C	Displays the last 8 values prior to the switch off with error
–	11338	P00-33 Counter for critical O-I errors	0 – 65000	Counter for overcurrent faults
–	11339	P00-34 Counter for critical O-Volt errors	0 – 65000	Counter for overvoltage faults
–	11340	P00-35 Counter for critical U-Volt errors	0 – 65000	Counter for undervoltage faults
–	11341	P00-36 Counter for critical O-t errors	0 – 65000	Counter for overtemperature faults of the heat sink

Parameters	CANopen/Sbus index	Parameters/description	Display range	Explanation
–	11342	P00-37 Counter for critical bO-I errors	0 – 65000	Counter for short-circuit faults at the brake chopper
–	11343	P00-38 Counter for critical O-heat errors	0 – 65000	Counter for overtemperature faults – ambient temperature
–	11224	P00-39 Counter for Modbus communication errors	0 – 65000	
–	11225	P00-40 Counter for CANopen communication errors	0 – 65000	
–	11223	P00-41 Counter for internal I/O communication errors	0 – 65000	
–	11344	P00-42 Counter for internal μ C power section communication errors	0 – 65000	Counter for communication errors between the processors of the power electronics
–	11351 – 11352	P00-43 Inverter operating time		Total operating time of the inverter since manufacturing in h
–	–	P00-44 Current phase offset and reference value for U	Internal value	Entries: First is reference value, second is measured value – no decimal place for both values
–	–	P00-45 Current phase offset and reference value for V	Internal value	Entries: First is reference value, second is measured value – no decimal place for both values
–	–	P00-46 Current phase offset and reference value for W	Internal value	Entries: First is reference value, second is measured value – no decimal place for both values
–	11294 – 11295	P00-47 Total cyclic duration factor of fire mode		Total cyclic duration factor of the fire mode in h
18, 19	11226 – 11227	P00-48 Display values channel 1 and 2 internal oscilloscope	1: Value 2: Value	Current value of the latest oscilloscope measurement. Unit refers to the set size
–	11228 – 11229	P00-49 Display values channel 3 and 4 internal oscilloscope	3: Value 4: Value	Current value of the latest oscilloscope measurement. Unit refers to the set size
–	11355 – 11356	P00-50 Lib version and DSP bootloader version for motor control	Example: L 1.00 Example: b 1.00	2 entries: First for lib version of the motor control, second for DSP bootloader version. 2 decimal positions

9 Technical data

The next chapter contains the technical data.

9.1 Conformity

All products meet the following international standards:

- CE marking according to the Low Voltage Directive
- IEC 664-1 Insulation coordination for electrical equipment within low-voltage systems
- UL 508C Power conversion equipment
- EN 61800-3 Variable-speed electrical drives – part 3
- EN 61000-6 / -2, -3, -4 Interference immunity / Interference emission (EMC)
- Housing protection classes according to NEMA 250, EN 55011:2007
- Classification of flammability according to UL 94
- RCM
- cUL
- EAC

9.2 Information on ambient conditions

	Permitted conditions
Ambient temperature during operation	-10 to +50 °C for PWM frequency of 2 kHz (IP20) -10 to +40 °C for PWM frequency of 2 kHz (IP66 NEMA 4X / IP55 NEMA 12K)
Maximum derating depending on the ambient temperature	4 %/1 °C to 55 °C for IP20 frequency inverters 4 %/1 °C to 45 °C for IP66/IP55 frequency inverter
Ambient temperature during storage	-40 °C to +60 °C
Maximum installation altitude for nominal operation	1000 m
Derating above 1000 m	1 %/100 m to max. 2000 m
Relative humidity	< 95 % (condensation not permitted)
Degree of protection of control cabinet inverter	IP20 NEMA 1
Frequency inverter with high degree of protection	IP66 NEMA 4X/IP55 NEMA 12K

9.3 Output power and current carrying capacity without EMC filter

Whether the MOVITRAC® LTE-B frequency inverters are used with or without filters depends on the regulations applicable in the various countries where the product is used.

- **Without filter: permitted in America, Asia, and Africa.**
- With filter: suited for use worldwide.

The specification "horsepower" (HP) is defined as follows.

- 200 – 240 V units: NEC2002, table 430-150, 230 V
- 380 – 480 V units: NEC2002, table 430-150, 460 V

9.3.1 1-phase system AC 115 V for 3-phase AC 230 V motors (voltage doubler)

MOVITRAC® LTE-B – EMC filter class 0					
IP20	Type	MC LTE B...	0004-101-1-00	0008-101-1-00	0011-101-4-00
	Part number		18261663	18261671	18261868
IP66/NEMA-4X housing without switches	Type	MC LTE B...	0004-101-1-30	0008-101-1-30	0011-101-4-30
	Part number		18262171	18262198	18262287
IP66/NEMA-4X housing with switches	Type	MC LTE B...	0004-101-1-40	0008-101-1-40	0011-101-4-40
	Part number		18262422	18262430	18262538
INPUT					
Line voltage V_{line}		V	1 × AC 110 – 115 ± 10%		
Line frequency f_{line}		Hz	50/60 ± 5%		
Line fuse		A	10	16 (15) ¹⁾	20
Nominal input current		A	6.7	12.5	16.8
OUTPUT					
Recommended motor power		kW	0.37	0.75	1.1
Output voltage V_{motor}		V	3 × 0 – 250		
Output current		A	2.3	4.3	5.8
Maximum output frequency		Hz	500		
Cross section of motor cable Cu 75C		mm²	1.5		
		AWG	16		
Max. motor cable length	Shielded	m	50		100
	Unshielded		75		150
GENERAL INFORMATION					
Size		Size	1		2
Heat loss at nominal output power		W	11	22	33
Minimum braking resistance value		Ω	–		47

1) Recommended values for UL compliance

9.3.2 1-phase system AC 230 V for 3-phase AC 230 V motors

MOVITRAC® LTE-B – EMC filter class 0								
IP20 ¹⁾	Type	MC LTE B...	0004-201-1-00	0008-201-1-00	0015-201-1-00	0015-201-4-00	0022-201-4-00	0040-201-4-00
	Part number		18261698	18261736	18261760	18261876	18261906	18262120
INPUT								
Line voltage V _{line}		V	1 × AC 200 – 240 ± 10%					
Line frequency f _{line}		Hz	50/60 ± 5%					
Line fuse		A	10	16	20	32 (35) ²⁾	40	
Nominal input current		A	6.7	12.5	14.8	22.2	31.7	
OUTPUT								
Recommended motor power		kW	0.37	0.75	1.5	2.2	4	
Output voltage V _{motor}		V	0 – V _{line}					
Output current		A	2.3	4.3	7	10.5	16	
Maximum output frequency		Hz	500					
Cross section of motor cable Cu 75C		mm ²	1.5					2.5
		AWG	16					18
Max. motor cable length	Shielded	m	50			100		
	Unshielded		75			150		
GENERAL INFORMATION								
Size		Size	1			2		3
Heat loss at nominal output power		W	11	22	45	66	120	
Minimum braking resistance value		Ω	–			47		

1) Device for America, Asia, and Africa

2) Recommended values for UL compliance

9.3.3 3-phase system AC 230 V for 3-phase AC 230 V motors

MOVITRAC® LTE-B – EMC filter class 0								
IP20 ¹⁾	Type	MC LTE B...	0004-203-1-00	0008-203-1-00	0015-203-1-00	0015-203-4-00	0022-203-4-00	0040-203-4-00
	Part number		18261701	18261744	18261779	18262023	18261914	18262031
INPUT								
Line voltage V _{line}		V	3 × AC 200 – 240 ± 10%					
Line frequency f _{line}		Hz	50/60 ± 5%					
Line fuse		A	6	10	16 (15) ²⁾		20	32 (35) ²⁾
Nominal input current		A	3	5.8	9.2		13.7	20.7
OUTPUT								
Recommended motor power		kW	0.37	0.75	1.5		2.2	4
Output voltage V _{motor}		V	0 – V _{line}					
Output current		A	2.3	4.3	7		10.5	18
Maximum output frequency		Hz	500					
Cross section of motor cable Cu 75C		mm ²	1.5					2.5
		AWG	16					12
Max. motor cable length	Shielded	m	50			100		
	Unshielded		75			150		
GENERAL INFORMATION								
Size		Size	1			2		3
Heat loss at nominal output power		W	11	22	45		66	120
Minimum braking resistance value		Ω	–			47		

1) Device for America, Asia, and Africa

2) Recommended values for UL compliance

9.3.4 3-phase system AC 400 V for 3-phase AC 400 V motors

Sizes 1 and 2

MOVITRAC® LTE-B – EMC filter class 0							
IP20 ¹⁾	Type	MC LTE B...	0008-503-1-00	0015-503-1-00	0015-503-4-00	0022-503-4-00	0040-503-4-00
	Part number		18261795	18261817	18261949	18261965	18261981
INPUT							
Line voltage V _{line}		V	3 × AC 380 – 480 ± 10%				
Line frequency f _{line}		Hz	50/60 ± 5%				
Line fuse		A	5	10			16 (15) ²⁾
Nominal input current		A	2.9	5.4	7.6	12.4	
OUTPUT							
Recommended motor power		kW	0.75	1.5	2.2	4	
Output voltage V _{motor}		V	0 – V _{line}				
Output current		A	2.2	4.1	5.8	9.5	
Maximum output frequency		Hz	500				
Cross section of motor cable Cu 75C		mm ²	1.5				
		AWG	16				
Max. motor cable length	Shielded	m	50	100			
	Unshielded		75	150			
GENERAL INFORMATION							
Size		Size	1	2			
Heat loss at nominal output power		W	22	45	66	120	
Minimum braking resistance value		Ω	–			100	

1) Device for America, Asia, and Africa

2) Recommended values for UL compliance

Size 3

MOVITRAC® LTE-B – EMC filter class 0					
IP20 ¹⁾	Type	MC LTE B...	0055-503-4-00	0075-503-4-00	0110-503-4-00
	Part number		18262066	18262082	18262104
INPUT					
Line voltage V_{line}		V	3 × AC 380 – 480 ± 10%		
Line frequency f_{line}		Hz	50/60 ± 5%		
Line fuse		A	20	25	32 (35) ²⁾
Nominal input current		A	16.1	20.7	27.1
OUTPUT					
Recommended motor power		kW	5.5	7.5	11
Output voltage V_{motor}		V	0 – V_{line}		
Output current		A	14	18	24
Maximum output frequency		Hz	500		
Cross section of motor cable Cu 75C		mm ²	2.5		4
		AWG	12		10
Max. motor cable length	Shielded	m	100		
	Unshielded		150		
GENERAL INFORMATION					
Size		Size	3		
Heat loss at nominal output power		W	165	225	330
Minimum braking resistance value		Ω	47		

1) Device for America, Asia, and Africa

2) Recommended values for UL compliance

9.4 Output power and current carrying capacity with EMC filter

Whether the MOVITRAC® LTE-B frequency inverters are used with or without filters depends on the regulations applicable in the various countries where the product is used.

- **With filter: suited for use worldwide.**
- Without filter: permitted in America, Asia, and Africa.

The specification "horsepower" (HP) is defined as follows.

- 200 – 240 V units: NEC2002, table 430-150, 230 V
- 380 – 480 V units: NEC2002, table 430-150, 460 V

9.4.1 1-phase system AC 230 V for 3-phase AC 230 V motors

MOVITRAC® LTE-B – EMC filter class B								
IP20 ¹⁾	Type	MC LTE B...	0004-2B1-1-00	0008-2B1-1-00	0015-2B1-1-00	0015-2B1-4-00	0022-2B1-4-00	0040-2B1-4-00
	Part number		18261728	18261752	18261787	18261892	18261930	18262139
IP66/ NEMA-4X housing without switches	Type	MC LTE B...	0004-2B1-1-30	0008-2B1-1-30	0015-2B1-1-30	0015-2B1-4-30	0022-2B1-4-30	0040-2B1-4-30
	Part number		18262201	18262228	18262236	18262295	18262309	18262384
IP66/ NEMA-4X housing with switches	Type	MC LTE B...	0004-2B1-1-40	0008-2B1-1-40	0015-2B1-1-40	0015-2B1-4-40	0022-2B1-4-40	0040-2B1-4-40
	Part number		18262503	18262511	18251048	18262570	18262589	18262597
INPUT								
Line voltage V _{line}		V	1 × AC 200 – 240 ± 10%					
Line frequency f _{line}		Hz	50/60 ± 5%					
Line fuse		A	10	16	20		32 (35) ²⁾	40
Nominal input current		A	6.7	12.5	14.8		22.2	31.7
OUTPUT								
Recommended motor power		kW	0.37	0.75	1.5		2.2	4
Output voltage V _{motor}		V	0 – V _{line}					
Output current		A	2.3	4.3	7		10.5	16
Maximum output frequency		Hz	500					
Cross section of motor cable Cu 75C		mm ²	1.5					2.5
		AWG	16					18
Max. motor cable length	Shielded	m	50			100		
	Unshielded		75			150		
GENERAL INFORMATION								
Size		Size	1			2		3
Heat loss at nominal output power		W	11	22	45		66	120
Minimum braking resistance value		Ω	-			47		

1) Device for Europe, Australia, and New Zealand

2) Recommended values for UL compliance

9.4.2 3-phase system AC 230 V for 3-phase AC 230 V motors

MOVITRAC® LTE-B – EMC filter class A					
IP20 ¹⁾	Type	MC LTE B...	0015-2A3-4-00	0022-2A3-4-00	0040-2A3-4-00
	Part number		18261884	18261922	18262058
IP66/NEMA-4X housing without switches	Type	MC LTE B...	0015-2A3-4-30	0022-2A3-4-30	0040-2A3-4-30
	Part number		18262317	18262325	18262392
IP66/NEMA-4X housing with switches	Type	MC LTE B...	0015-2A3-4-40	0022-2A3-4-40	0040-2A3-4-40
	Part number		18262600	18262619	18262635
INPUT					
Line voltage V_{line}		V	3 × AC 200 – 240 ± 10%		
Line frequency f_{line}		Hz	50/60 ± 5%		
Line fuse		A	16 (15) ²⁾	20	32 (35)
Nominal input current		A	9.2	13.7	20.7
OUTPUT					
Recommended motor power		kW	1.5	2.2	4.0
Output voltage V_{motor}		V	0 – V_{line}		
Output current		A	7	10.5	18
Maximum output frequency		Hz	500		
Cross section of motor cable Cu 75C		mm ²	1.5		2.5
		AWG	16		12
Max. motor cable length	Shielded	m	100		
	Unshielded		150		
GENERAL INFORMATION					
Size		Size	2		3
Heat loss at nominal output power		W	45	66	120
Minimum braking resistance value		Ω	47		

1) Device for Europe, Australia, and New Zealand

2) Recommended values for UL compliance

9.4.3 3-phase system AC 400 V for 3-phase AC 400 V motors

Sizes 1 and 2

MOVITRAC® LTE-B – EMC filter class A							
IP20 ¹⁾	Type	MC LTE B...	0008-5A3-1-00	0015-5A3-1-00	0015-5A3-4-00	0022-5A3-4-00	0040-5A3-4-00
	Part number		18261809	18261825	18261957	18261973	18262007
IP66/NEMA-4X housing without switches	Type	MC LTE B...	0008-5A3-1-30	0015-5A3-1-30	0015-5A3-4-30	0022-5A3-4-30	0040-5A3-4-30
	Part number		18262244	18262252	18262333	18262341	18262368
IP66/NEMA-4X housing with switches	Type	MC LTE B...	0008-5A3-1-40	0015-5A3-1-40	0015-5A3-4-40	0022-5A3-4-40	0040-5A3-4-40
	Part number		18251145	18251153	18262546	18262554	18262562
INPUT							
Line voltage V _{line}		V	3 × AC 380 – 480 ± 10%				
Line frequency f _{line}		Hz	50/60 ± 5%				
Line fuse		A	5	10			16 (15) ²⁾
Nominal input current		A	2.9	5.4		7.6	12.4
OUTPUT							
Recommended motor power		kW	0.75	1.5		2.2	4
Output voltage V _{motor}		V	0 – V _{line}				
Output current		A	2.2	4.1		5.8	9.5
Maximum output frequency		Hz	500				
Cross section of motor cable Cu 75C		mm ²	1.5				
		AWG	16				
Max. motor cable length	Shielded	m	50		100		
	Unshielded		75		150		
GENERAL INFORMATION							
Size		Size	1		2		
Heat loss at nominal output power		W	22	45		66	120
Minimum braking resistance value		Ω	-		100		

1) Device for Europe, Australia, and New Zealand

2) Recommended values for UL compliance

Size 3

MOVITRAC® LTE-B – EMC filter class A					
IP20 ¹⁾	Type	MC LTE B...	0055-5A3-4-00	0075-5A3-4-00	0110-5A3-4-00
	Part number		18262074	18262090	18262112
IP66/NEMA-4X housing without switches	Type	MC LTE B...	0055-5A3-4-30	0075-5A3-4-30	-
	Part number		18262406	18262414	-
IP66/NEMA-4X housing with switches	Type	MC LTE B...	0055-5A3-4-40	0075-5A3-4-40	-
	Part number		18262643	18262651	-
INPUT					
Line voltage V_{line}		V	3 × AC 380 – 480 ± 10%		
Line frequency f_{line}		Hz	50/60 ± 5%		
Line fuse		A	20	25	32 (35) ²⁾
Nominal input current		A	16.1	20.1	27.1
OUTPUT					
Recommended motor power		kW	5.5	7.5	11
Output voltage V_{motor}		V	0 – V_{line}		
Output current		A	14	18	24
Maximum output frequency		Hz	500		
Cross section of motor cable Cu 75C		mm ²	2.5		4
		AWG	12		10
Max. motor cable length	Shielded	m	100		
	Unshielded		150		
GENERAL INFORMATION					
Size		Size	3		
Heat loss at nominal output power		W	165	225	330
Minimum braking resistance value		Ω	47		

1) Device for Europe, Australia, and New Zealand

2) Recommended values for UL compliance

10 Declaration of Conformity

EU Declaration of Conformity



Translation of the original text

900720110/EN

SEW-EURODRIVE GmbH & Co. KG
Ernst-Blickle-Straße 42, D-76646 Bruchsal

declares under sole responsibility that the following products

Frequency inverters of the series **MOVITRAC® LTE B**
are in conformity with

Low Voltage Directive **2006/95/EC (valid until April 19, 2016)**
 2014/35/EU (valid as of April 20, 2016)
 (L 96, 29.03.2014, 357-374)

EMC Directive **2004/108/EC (valid until April 19, 2016)** **4)**
 2014/30/EU (valid as of April 20, 2016) **4)**
 (L 96, 29.03.2014, 79-106)

Applied harmonized standards: **EN 61800-5-1:2003**
 EN 61800-3:2004/A1:2012

4) According to the EMC Directive, the listed products are not independently operable products. EMC assessment is only possible after these products have been integrated in an overall system. For the assessment, the product was installed in a typical plant configuration.

Bruchsal

12.04.2016

Place

Date

Johann Soder
 Managing Director Technology

a) b)

- a) Authorized representative for issuing this declaration on behalf of the manufacturer
 b) Authorized representative for compiling the technical documents

11 Address list

Algeria			
Sales	Algiers	REDUCOM Sarl 16, rue des Frères Zaghroune Bellevue 16200 El Harrach Alger	Tel. +213 21 8214-91 Fax +213 21 8222-84 http://www.reducom-dz.com info@reducom-dz.com
Argentina			
Assembly Sales	Buenos Aires	SEW EURODRIVE ARGENTINA S.A. Ruta Panamericana Km 37.5, Lote 35 (B1619IEA) Centro Industrial Garín Prov. de Buenos Aires	Tel. +54 3327 4572-84 Fax +54 3327 4572-21 http://www.sew-eurodrive.com.ar sewar@sew-eurodrive.com.ar
Australia			
Assembly Sales Service	Melbourne	SEW-EURODRIVE PTY. LTD. 27 Beverage Drive Tullamarine, Victoria 3043	Tel. +61 3 9933-1000 Fax +61 3 9933-1003 http://www.sew-eurodrive.com.au enquires@sew-eurodrive.com.au
	Sydney	SEW-EURODRIVE PTY. LTD. 9, Sleigh Place, Wetherill Park New South Wales, 2164	Tel. +61 2 9725-9900 Fax +61 2 9725-9905 enquires@sew-eurodrive.com.au
Austria			
Assembly Sales Service	Vienna	SEW-EURODRIVE Ges.m.b.H. Richard-Strauss-Straße 24 1230 Wien	Tel. +43 1 617 55 00-0 Fax +43 1 617 55 00-30 http://www.sew-eurodrive.at sew@sew-eurodrive.at
Bangladesh			
Sales	Bangladesh	SEW-EURODRIVE INDIA PRIVATE LIMITED 345 DIT Road East Rampura Dhaka-1219, Bangladesh	Tel. +88 01729 097309 salesdhaka@seweurodrivebangladesh.com
Belarus			
Sales	Minsk	Foreign unitary production enterprise SEW- EURODRIVE RybalkoStr. 26 220033 Minsk	Tel. +375 17 298 47 56 / 298 47 58 Fax +375 17 298 47 54 http://www.sew.by sales@sew.by
Belgium			
Assembly Sales Service	Brussels	SEW-EURODRIVE n.v./s.a. Researchpark Haasrode 1060 Evenementenlaan 7 3001 Leuven	Tel. +32 16 386-311 Fax +32 16 386-336 http://www.sew-eurodrive.be info@sew-eurodrive.be
Service Competence Center	Industrial Gears	SEW-EURODRIVE n.v./s.a. Rue de Parc Industriel, 31 6900 Marche-en-Famenne	Tel. +32 84 219-878 Fax +32 84 219-879 http://www.sew-eurodrive.be service-IG@sew-eurodrive.be
Brazil			
Production Sales Service	São Paulo	SEW-EURODRIVE Brasil Ltda. Estrada Municipal José Rubim, 205 – Rodovia Santos Dumont Km 49 Indaiatuba – 13347-510 – SP	Tel. +55 19 3835-8000 sew@sew.com.br
Assembly Sales Service	Rio Claro	SEW-EURODRIVE Brasil Ltda. Rodovia Washington Luiz, Km 172 Condomínio Industrial Conpark Caixa Postal: 327 13501-600 – Rio Claro / SP	Tel. +55 19 3522-3100 Fax +55 19 3524-6653 montadora.rc@sew.com.br
	Joinville	SEW-EURODRIVE Brasil Ltda. Rua Dona Francisca, 12.346 – Pirabeiraba 89239-270 – Joinville / SC	Tel. +55 47 3027-6886 Fax +55 47 3027-6888 filial.sc@sew.com.br
Bulgaria			
Sales	Sofia	BEVER-DRIVE GmbH Bogdanovetz Str.1 1606 Sofia	Tel. +359 2 9151160 Fax +359 2 9151166 bever@bever.bg

Cameroon

Sales	Douala	SEW-EURODRIVE S.A.R.L. Ancienne Route Bonabéri P.O. Box B.P 8674 Douala-Cameroun	Tel. +237 233 39 02 10 Fax +237 233 39 02 10 info@sew-eurodrive-cm
-------	--------	--	--

Canada

Assembly Sales Service	Toronto	SEW-EURODRIVE CO. OF CANADA LTD. 210 Walker Drive Bramalea, ON L6T 3W1	Tel. +1 905 791-1553 Fax +1 905 791-2999 http://www.sew-eurodrive.ca l.watson@sew-eurodrive.ca
	Vancouver	SEW-EURODRIVE CO. OF CANADA LTD. Tilbury Industrial Park 7188 Honeyman Street Delta, BC V4G 1G1	Tel. +1 604 946-5535 Fax +1 604 946-2513 b.wake@sew-eurodrive.ca
	Montreal	SEW-EURODRIVE CO. OF CANADA LTD. 2555 Rue Leger Lasalle, PQ H8N 2V9	Tel. +1 514 367-1124 Fax +1 514 367-3677 a.peluso@sew-eurodrive.ca

Chile

Assembly Sales Service	Santiago de Chile	SEW-EURODRIVE CHILE LTDA Las Encinas 1295 Parque Industrial Valle Grande LAMP Santiago de Chile P.O. Box Casilla 23 Correo Quilicura - Santiago - Chile	Tel. +56 2 2757 7000 Fax +56 2 2757 7001 http://www.sew-eurodrive.cl ventas@sew-eurodrive.cl
------------------------------	-------------------	---	---

China

Production Assembly Sales Service	Tianjin	SEW-EURODRIVE (Tianjin) Co., Ltd. No. 78, 13th Avenue, TEDA Tianjin 300457	Tel. +86 22 25322612 Fax +86 22 25323273 http://www.sew-eurodrive.cn info@sew-eurodrive.cn
Assembly Sales Service	Suzhou	SEW-EURODRIVE (Suzhou) Co., Ltd. 333, Suhong Middle Road Suzhou Industrial Park Jiangsu Province, 215021	Tel. +86 512 62581781 Fax +86 512 62581783 suzhou@sew-eurodrive.cn
	Guangzhou	SEW-EURODRIVE (Guangzhou) Co., Ltd. No. 9, JunDa Road East Section of GETDD Guangzhou 510530	Tel. +86 20 82267890 Fax +86 20 82267922 guangzhou@sew-eurodrive.cn
	Shenyang	SEW-EURODRIVE (Shenyang) Co., Ltd. 10A-2, 6th Road Shenyang Economic Technological Development Area Shenyang, 110141	Tel. +86 24 25382538 Fax +86 24 25382580 shenyang@sew-eurodrive.cn
	Taiyuan	SEW-EURODRIVE (Taiyuan) Co., Ltd. No.3, HuaZhang Street, TaiYuan Economic & Technical Development Zone ShanXi, 030032	Tel. +86-351-7117520 Fax +86-351-7117522 taiyuan@sew-eurodrive.cn
	Wuhan	SEW-EURODRIVE (Wuhan) Co., Ltd. 10A-2, 6th Road No. 59, the 4th Quanli Road, WEDA 430056 Wuhan	Tel. +86 27 84478388 Fax +86 27 84478389 wuhan@sew-eurodrive.cn
	Xi'An	SEW-EURODRIVE (Xi'An) Co., Ltd. No. 12 Jinye 2nd Road Xi'An High-Technology Industrial Development Zone Xi'An 710065	Tel. +86 29 68686262 Fax +86 29 68686311 xian@sew-eurodrive.cn
Sales Service	Hong Kong	SEW-EURODRIVE LTD. Unit No. 801-806, 8th Floor Hong Leong Industrial Complex No. 4, Wang Kwong Road Kowloon, Hong Kong	Tel. +852 36902200 Fax +852 36902211 contact@sew-eurodrive.hk

Colombia			
Assembly Sales Service	Bogota	SEW-EURODRIVE COLOMBIA LTDA. Calle 17 No. 132-18 Interior 2 Bodega 6, Manzana B Santafé de Bogotá	Tel. +57 1 54750-50 Fax +57 1 54750-44 http://www.sew-eurodrive.com.co sew@sew-eurodrive.com.co
Croatia			
Sales Service	Zagreb	KOMPEKS d. o. o. Zeleni dol 10 10 000 Zagreb	Tel. +385 1 4613-158 Fax +385 1 4613-158 kompeks@inet.hr
Czech Republic			
Assembly Sales Service	Hostivice	SEW-EURODRIVE CZ s.r.o. Floriánova 2459 253 01 Hostivice	Tel. +420 255 709 601 Fax +420 235 350 613 http://www.sew-eurodrive.cz sew@sew-eurodrive.cz
	Drive Service Hotline / 24 Hour Service	+420 800 739 739 (800 SEW SEW)	Service Tel. +420 255 709 632 Fax +420 235 358 218 servis@sew-eurodrive.cz
Denmark			
Assembly Sales Service	Copenhagen	SEW-EURODRIVEA/S Geminivej 28-30 2670 Greve	Tel. +45 43 95 8500 Fax +45 43 9585-09 http://www.sew-eurodrive.dk sew@sew-eurodrive.dk
Egypt			
Sales Service	Cairo	Copam Egypt for Engineering & Agencies Building 10, Block 13005, First Industrial Zone, Obour City Cairo	Tel. +202 44812673 / 79 (7 lines) Fax +202 44812685 http://www.copam-egypt.com copam@copam-egypt.com
Estonia			
Sales	Tallin	ALAS-KUUL AS Reti tee 4 75301 Peetri küla, Rae vald, Harjumaa	Tel. +372 6593230 Fax +372 6593231 http://www.alas-kuul.ee veiko.soots@alas-kuul.ee
Finland			
Assembly Sales Service	Hollola	SEW-EURODRIVE OY Vesimäentie 4 15860 Hollola	Tel. +358 201 589-300 Fax +358 3 780-6211 http://www.sew-eurodrive.fi sew@sew.fi
Service	Hollola	SEW-EURODRIVE OY Keskikankaantie 21 15860 Hollola	Tel. +358 201 589-300 Fax +358 3 780-6211 http://www.sew-eurodrive.fi sew@sew.fi
Production Assembly	Karkkila	SEW Industrial Gears Oy Santasalonkatu 6, PL 8 03620 Karkkila, 03601 Karkkila	Tel. +358 201 589-300 Fax +358 201 589-310 http://www.sew-eurodrive.fi sew@sew.fi
France			
Production Sales Service	Hagenau	SEW-USOCOME 48-54 route de Soufflenheim B. P. 20185 67506 Haguenau Cedex	Tel. +33 3 88 73 67 00 Fax +33 3 88 73 66 00 http://www.usocom.com sew@usocom.com
Production	Forbach	SEW-USOCOME Zone industrielle Technopôle Forbach Sud B. P. 30269 57604 Forbach Cedex	Tel. +33 3 87 29 38 00
	Brumath	SEW-USOCOME 1 Rue de Bruxelles 67670 Mommenheim Cedex	Tel. +33 3 88 37 48 00
Assembly Sales Service	Bordeaux	SEW-USOCOME Parc d'activités de Magellan 62 avenue de Magellan – B. P. 182 33607 Pessac Cedex	Tel. +33 5 57 26 39 00 Fax +33 5 57 26 39 09

France

Lyon	SEW-USOCOME 75 rue Antoine Condorcet 38090 Vaulx-Milieu	Tel. +33 4 74 99 60 00 Fax +33 4 74 99 60 15
Nantes	SEW-USOCOME Parc d'activités de la forêt 4 rue des Fontenelles 44140 Le Bignon	Tel. +33 2 40 78 42 00 Fax +33 2 40 78 42 20
Paris	SEW-USOCOME Zone industrielle 2 rue Denis Papin 77390 Verneuil l'Étang	Tel. +33 1 64 42 40 80 Fax +33 1 64 42 40 88

Gabon

Sales	Libreville	SEW-EURODRIVE SARL 183, Rue 5.033.C, Lalala à droite P.O. Box 15682 Libreville	Tel. +241 03 28 81 55 +241 06 54 81 33 http://www.sew-eurodrive.cm sew@sew-eurodrive.cm
-------	------------	---	--

Germany

Headquarters Production Sales	Bruchsal	SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 42 76646 Bruchsal P.O. Box Postfach 3023 – D-76642 Bruchsal	Tel. +49 7251 75-0 Fax +49 7251 75-1970 http://www.sew-eurodrive.de sew@sew-eurodrive.de
Production / Industrial Gears	Bruchsal	SEW-EURODRIVE GmbH & Co KG Christian-Pähr-Str. 10 76646 Bruchsal	Tel. +49 7251 75-0 Fax +49 7251 75-2970
Production	Graben	SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 1 76676 Graben-Neudorf P.O. Box Postfach 1220 – D-76671 Graben-Neudorf	Tel. +49 7251 75-0 Fax +49 7251-2970
	Östringen	SEW-EURODRIVE GmbH & Co KG, Werk Östringen Franz-Gurk-Straße 2 76684 Östringen	Tel. +49 7253 9254-0 Fax +49 7253 9254-90 oesstringen@sew-eurodrive.de
Service Competence Center	Mechanics / Mechatronics	SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 1 76676 Graben-Neudorf	Tel. +49 7251 75-1710 Fax +49 7251 75-1711 scc-mechanik@sew-eurodrive.de
	Electronics	SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 42 76646 Bruchsal	Tel. +49 7251 75-1780 Fax +49 7251 75-1769 scc-elektronik@sew-eurodrive.de
Drive Technology Center	North	SEW-EURODRIVE GmbH & Co KG Alte Ricklinger Straße 40-42 30823 Garbsen (Hannover)	Tel. +49 5137 8798-30 Fax +49 5137 8798-55 dtc-nord@sew-eurodrive.de
	East	SEW-EURODRIVE GmbH & Co KG Dänkritzter Weg 1 08393 Meerane (Zwickau)	Tel. +49 3764 7606-0 Fax +49 3764 7606-30 dtc-ost@sew-eurodrive.de
	South	SEW-EURODRIVE GmbH & Co KG Domagkstraße 5 85551 Kirchheim (München)	Tel. +49 89 909552-10 Fax +49 89 909552-50 dtc-sued@sew-eurodrive.de
	West	SEW-EURODRIVE GmbH & Co KG Siemensstraße 1 40764 Langenfeld (Düsseldorf)	Tel. +49 2173 8507-30 Fax +49 2173 8507-55 dtc-west@sew-eurodrive.de
Drive Center	Berlin	SEW-EURODRIVE GmbH & Co KG Alexander-Meißner-Straße 44 12526 Berlin	Tel. +49 306331131-30 Fax +49 306331131-36 dc-berlin@sew-eurodrive.de
	Ludwigshafen	SEW-EURODRIVE GmbH & Co KG c/o BASF SE Gebäude W130 Raum 101 67056 Ludwigshafen	Tel. +49 7251 75 3759 Fax +49 7251 75 503759 dc-ludwigshafen@sew-eurodrive.de
	Saarland	SEW-EURODRIVE GmbH & Co KG Gottlieb-Daimler-Straße 4 66773 Schwalbach Saar – Hülzweiler	Tel. +49 6831 48946 10 Fax +49 6831 48946 13 dc-saarland@sew-eurodrive.de
	Ulm	SEW-EURODRIVE GmbH & Co KG Dieselstraße 18 89160 Dornstadt	Tel. +49 7348 9885-0 Fax +49 7348 9885-90 dc-ulm@sew-eurodrive.de

Germany			
	Würzburg	SEW-EURODRIVE GmbH & Co KG Nürnbergerstraße 118 97076 Würzburg-Lengfeld	Tel. +49 931 27886-60 Fax +49 931 27886-66 dc-wuerzburg@sew-eurodrive.de
Drive Service Hotline / 24 Hour Service			0 800 SEWHELP 0 800 7394357
Great Britain			
Assembly Sales Service	Normanton	SEW-EURODRIVE Ltd. DeVilliers Way Trident Park Normanton West Yorkshire WF6 1GX	Tel. +44 1924 893-855 Fax +44 1924 893-702 http://www.sew-eurodrive.co.uk info@sew-eurodrive.co.uk
Drive Service Hotline / 24 Hour Service			Tel. 01924 896911
Greece			
Sales	Athens	Christ. Boznos & Son S.A. 12, K. Mavromichali Street P.O. Box 80136 18545 Piraeus	Tel. +30 2 1042 251-34 Fax +30 2 1042 251-59 http://www.boznos.gr info@boznos.gr
Hungary			
Sales Service	Budapest	SEW-EURODRIVE Kft. Csillaghegyi út 13. 1037 Budapest	Tel. +36 1 437 06-58 Fax +36 1 437 06-50 http://www.sew-eurodrive.hu office@sew-eurodrive.hu
Iceland			
Sales	Reykjavik	Varma & Vélaverk ehf. Knarrarvogi 4 104 Reykjavik	Tel. +354 585 1070 Fax +354 585)1071 http://www.varmaverk.is vov@vov.is
India			
Registered Office Assembly Sales Service	Vadodara	SEW-EURODRIVE India Private Limited Plot No. 4, GIDC POR Ramangamdi • Vadodara - 391 243 Gujarat	Tel. +91 265 3045200 Fax +91 265 3045300 http://www.seweurodriveindia.com salesvadodara@seweurodriveindia.com
Assembly Sales Service	Chennai	SEW-EURODRIVE India Private Limited Plot No. K3/1, Sipcot Industrial Park Phase II Mambakkam Village Sriperumbudur - 602105 Kancheepuram Dist, Tamil Nadu	Tel. +91 44 37188888 Fax +91 44 37188811 saleschennai@seweurodriveindia.com
	Pune	SEW-EURODRIVE India Private Limited Plant: Plot No. D236/1, Chakan Industrial Area Phase- II, Warale, Tal- Khed, Pune-410501, Maharashtra	Tel. +91 21 35 628700 Fax +91 21 35 628715 salespune@seweurodriveindia.com
Indonesia			
Sales	Medan	PT. Serumpun Indah Lestari Jl.Pulau Solor no. 8, Kawasan Industri Medan II Medan 20252	Tel. +62 61 687 1221 Fax +62 61 6871429 / +62 61 6871458 / +62 61 30008041 sil@serumpunindah.com serumpunindah@yahoo.com http://www.serumpunindah.com
	Jakarta	PT. Cahaya Sukses Abadi Komplek Rukan Puri Mutiara Blok A no 99, Sunter Jakarta 14350	Tel. +62 21 65310599 Fax +62 21 65310600 csajkt@cbn.net.id
	Jakarta	PT. Agrindo Putra Lestari Jl.Pantai Indah Selatan, Komplek Sentra Industri Terpadu, Pantai indah Kapuk Tahap III, Blok E No. 27 Jakarta 14470	Tel. +62 21 2921-8899 Fax +62 21 2921-8988 aplindo@indosat.net.id http://www.aplindo.com

Indonesia			
	Surabaya	PT. TRIAGRI JAYA ABADI Jl. Sukosemolo No. 63, Galaxi Bumi Permai G6 No. 11 Surabaya 60111	Tel. +62 31 5990128 Fax +62 31 5962666 sales@triagri.co.id http://www.triagri.co.id
	Surabaya	CV. Multi Mas Jl. Raden Saleh 43A Kav. 18 Surabaya 60174	Tel. +62 31 5458589 Fax +62 31 5317220 sianhwa@sby.centrin.net.id http://www.cvmultimas.com
Ireland			
Sales Service	Dublin	Alperton Engineering Ltd. 48 Moyle Road Dublin Industrial Estate Glasnevin, Dublin 11	Tel. +353 1 830-6277 Fax +353 1 830-6458 http://www.alperton.ie info@alperton.ie
Israel			
Sales	Tel Aviv	Liraz Handasa Ltd. Ahofer Str 34B / 228 58858 Holon	Tel. +972 3 5599511 Fax +972 3 5599512 http://www.liraz-handasa.co.il office@liraz-handasa.co.il
Italy			
Assembly Sales Service	Milan	SEW-EURODRIVE di R. Blickle & Co.s.a.s. Via Bernini, 14 20020 Solaro (Milano)	Tel. +39 02 96 980229 Fax +39 02 96 980 999 http://www.sew-eurodrive.it milano@sew-eurodrive.it
Ivory Coast			
Sales	Abidjan	SEW-EURODRIVE SARL Ivory Coast Rue des Pêcheurs, Zone 3 26 BP 916 Abidjan 26	Tel. +225 21 21 81 05 Fax +225 21 25 30 47 info@sew-eurodrive.ci http://www.sew-eurodrive.ci
Japan			
Assembly Sales Service	Iwata	SEW-EURODRIVE JAPAN CO., LTD 250-1, Shimoman-no, Iwata Shizuoka 438-0818	Tel. +81 538 373811 Fax +81 538 373814 http://www.sew-eurodrive.co.jp sewjapan@sew-eurodrive.co.jp hamamatsu@sew-eurodrive.co.jp
Kazakhstan			
Sales	Almaty	SEW-EURODRIVE LLP 291-291A, Tole bi street 050031, Almaty	Tel. +7 (727) 350 5156 Fax +7 (727) 350 5156 http://www.sew-eurodrive.kz sew@sew-eurodrive.kz
	Tashkent	SEW-EURODRIVE LLP Representative office in Uzbekistan 96A, Sharaf Rashidov street, Tashkent, 100084	Tel. +998 71 2359411 Fax +998 71 2359412 http://www.sew-eurodrive.uz sew@sew-eurodrive.uz
	Ulaanbaatar	IM Trading LLC Narny zam street 62 Sukhbaatar district, Ulaanbaatar 14230	Tel. +976-77109997 Fax +976-77109997 imt@imt.mn
Kenya			
Sales	Nairobi	SEW-EURODRIVE Pty Ltd Transnational Plaza, 5th Floor Mama Ngina Street P.O. Box 8998-00100 Nairobi	Tel. +254 791 398840 http://www.sew-eurodrive.co.tz info@sew.co.tz
Latvia			
Sales	Riga	SIA Alas-Kuul Katlakalna 11C 1073 Riga	Tel. +371 6 7139253 Fax +371 6 7139386 http://www.alas-kuul.lv info@alas-kuul.com

Lebanon			
Sales (Lebanon)	Beirut	Gabriel Acar & Fils sarl B. P. 80484 Bourj Hammoud, Beirut	Tel. +961 1 510 532 Fax +961 1 494 971 ssacar@inco.com.lb
Sales (Jordan, Kuwait , Beirut Saudi Arabia, Syria)		Middle East Drives S.A.L. (offshore) Sin El Fil. B. P. 55-378 Beirut	Tel. +961 1 494 786 Fax +961 1 494 971 http://www.medrives.com info@medrives.com
Lithuania			
Sales	Alytus	UAB Irseva Statybininku 106C 63431 Alytus	Tel. +370 315 79204 Fax +370 315 56175 http://www.irseva.lt irmantas@irseva.lt
Luxembourg			
representation: Belgium			
Macedonia			
Sales	Skopje	Boznos DOOEL Dime Anicin 2A/7A 1000 Skopje	Tel. +389 23256553 Fax +389 23256554 http://www.boznos.mk
Malaysia			
Assembly Sales Service	Johor	SEW-EURODRIVE SDN BHD No. 95, Jalan Seroja 39, Taman Johor Jaya 81000 Johor Bahru, Johor West Malaysia	Tel. +60 7 3549409 Fax +60 7 3541404 sales@sew-eurodrive.com.my
Mexiko			
Assembly Sales Service	Quéretaro	SEW-EURODRIVE MEXICO S.A. de C.V. SEM-981118-M93 Tequisquiapan No. 102 Parque Industrial Quéretaro C.P. 76220 Querétaro, México	Tel. +52 442 1030-300 Fax +52 442 1030-301 http://www.sew-eurodrive.com.mx scmexico@sew-eurodrive.com.mx
Sales Service	Puebla	SEW-EURODRIVE MEXICO S.A. de C.V. Calzada Zavaleta No. 3922 Piso 2 Local 6 Col. Santa Cruz Buenavista C.P. 72154 Puebla, México	Tel. +52 (222) 221 248 http://www.sew-eurodrive.com.mx scmexico@sew-eurodrive.com.mx
Mongolia			
Technical Office	Ulaanbaatar	IM Trading LLC Narny zam street 62 Union building, Suite A-403-1 Sukhbaatar district, Ulaanbaatar 14230	Tel. +976-77109997 Tel. +976-99070395 Fax +976-77109997 http://imt.mn/ imt@imt.mn
Morocco			
Sales Service	Bouskoura	SEW-EURODRIVE Morocco Parc Industriel CFCIM, Lot 55 and 59 Bouskoura	Tel. +212 522 88 85 00 Fax +212 522 88 84 50 http://www.sew-eurodrive.ma sew@sew-eurodrive.ma
Namibia			
Sales	Swakopmund	DB Mining & Industrial Services Einstein Street Strauss Industrial Park Unit1 Swakopmund	Tel. +264 64 462 738 Fax +264 64 462 734 anton@dbminingnam.com
Netherlands			
Assembly Sales Service	Rotterdam	SEW-EURODRIVE B.V. Industrieweg 175 3044 AS Rotterdam Postbus 10085 3004 AB Rotterdam	Tel. +31 10 4463-700 Fax +31 10 4155-552 Service: 0800-SEWHELP http://www.sew-eurodrive.nl info@sew-eurodrive.nl

New Zealand			
Assembly Sales Service	Auckland	SEW-EURODRIVE NEW ZEALAND LTD. P.O. Box 58-428 82 Greenmount drive East Tamaki Auckland	Tel. +64 9 2745627 Fax +64 9 2740165 http://www.sew-eurodrive.co.nz sales@sew-eurodrive.co.nz
	Christchurch	SEW-EURODRIVE NEW ZEALAND LTD. 30 Lodestar Avenue, Wigram Christchurch	Tel. +64 3 384-6251 Fax +64 3 384-6455 sales@sew-eurodrive.co.nz
Nigeria			
Sales	Lagos	Greenpeg Nig. Ltd Plot 296A, Adeyemo Akapo Str. Omole GRA Ikeja Lagos-Nigeria	Tel. +234-701-821-9200-1 http://www.greenpegltd.com bolaji.adekunle@greenpegltd.com
Norway			
Assembly Sales Service	Moss	SEW-EURODRIVE A/S Solgaard skog 71 1599 Moss	Tel. +47 69 24 10 20 Fax +47 69 24 10 40 http://www.sew-eurodrive.no sew@sew-eurodrive.no
Pakistan			
Sales	Karachi	Industrial Power Drives Al-Fatah Chamber A/3, 1st Floor Central Com- mercial Area, Sultan Ahmed Shah Road, Block 7/8, Karachi	Tel. +92 21 452 9369 Fax +92-21-454 7365 seweurodrive@cyber.net.pk
Paraguay			
Sales	Fernando de la Mora	SEW-EURODRIVE PARAGUAY S.R.L De la Victoria 112, Esquina nueva Asunción Departamento Central Fernando de la Mora, Barrio Bernardino	Tel. +595 991 519695 Fax +595 21 3285539 sewpy@sew-eurodrive.com.py
Peru			
Assembly Sales Service	Lima	SEW EURODRIVE DEL PERU S.A.C. Los Calderos, 120-124 Urbanizacion Industrial Vulcano, ATE, Lima	Tel. +51 1 3495280 Fax +51 1 3493002 http://www.sew-eurodrive.com.pe sewperu@sew-eurodrive.com.pe
Philippines			
Sales	Makati	P.T. Cerna Corporation 4137 Ponte St., Brgy. Sta. Cruz Makati City 1205	Tel. +63 2 519 6214 Fax +63 2 890 2802 mech_drive_sys@ptcerna.com http://www.ptcerna.com
Poland			
Assembly Sales Service	Łódź	SEW-EURODRIVE Polska Sp.z.o.o. ul. Techniczna 5 92-518 Łódź	Tel. +48 42 293 00 00 Fax +48 42 293 00 49 http://www.sew-eurodrive.pl sew@sew-eurodrive.pl
	Service	Tel. +48 42 293 0030 Fax +48 42 293 0043	24 Hour Service Tel. +48 602 739 739 (+48 602 SEW SEW) serwis@sew-eurodrive.pl
Portugal			
Assembly Sales Service	Coimbra	SEW-EURODRIVE, LDA. Av. da Fonte Nova, n.º 86 3050-379 Mealhada	Tel. +351 231 20 9670 Fax +351 231 20 3685 http://www.sew-eurodrive.pt infosew@sew-eurodrive.pt
Romania			
Sales Service	Bucharest	Sialco Trading SRL str. Brazilia nr. 36 011783 Bucuresti	Tel. +40 21 230-1328 Fax +40 21 230-7170 sialco@sialco.ro
Russia			
Assembly Sales Service	St. Petersburg	ЗАО «СЕВ-ЕВРОДРАЙФ» а. я. 36 195220 Санкт-Петербург	Tel. +7 812 3332522 / +7 812 5357142 Fax +7 812 3332523 http://www.sew-eurodrive.ru sew@sew-eurodrive.ru

Sambia

representation: South Africa

Senegal

Sales	Dakar	SENEMECA Mécanique Générale Km 8, Route de Rufisque B.P. 3251, Dakar	Tel. +221 338 494 770 Fax +221 338 494 771 http://www.senemeca.com senemeca@senemeca.sn
-------	-------	---	--

Serbia

Sales	Belgrade	DIPAR d.o.o. Ustanicka 128a PC Košum, IV floor 11000 Beograd	Tel. +381 11 347 3244 / +381 11 288 0393 Fax +381 11 347 1337 office@dipar.rs
-------	----------	---	--

Singapore

Assembly Sales Service	Singapore	SEW-EURODRIVE PTE. LTD. No 9, Tuas Drive 2 Jurong Industrial Estate Singapore 638644	Tel. +65 68621701 Fax +65 68612827 http://www.sew-eurodrive.com.sg sewsingapore@sew-eurodrive.com
------------------------------	-----------	---	--

Slovakia

Sales	Bratislava	SEW-Eurodrive SK s.r.o. Rybničná 40 831 06 Bratislava	Tel. +421 2 33595 202, 217, 201 Fax +421 2 33595 200 http://www.sew-eurodrive.sk sew@sew-eurodrive.sk
	Košice	SEW-Eurodrive SK s.r.o. Slovenská ulica 26 040 01 Košice	Tel. +421 55 671 2245 Fax +421 55 671 2254 Mobile +421 907 671 976 sew@sew-eurodrive.sk

Slovenia

Sales Service	Celje	Pakman - Pogonska Tehnika d.o.o. Ul. XIV. divizije 14 3000 Celje	Tel. +386 3 490 83-20 Fax +386 3 490 83-21 pakman@siol.net
------------------	-------	--	---

South Africa

Assembly Sales Service	Johannesburg	SEW-EURODRIVE (PROPRIETARY) LIMITED Eurodrive House Cnr. Adcock Ingram and Aerodrome Roads Aeroton Ext. 2 Johannesburg 2013 P.O.Box 90004 Bertsham 2013	Tel. +27 11 248-7000 Fax +27 11 248-7289 http://www.sew.co.za info@sew.co.za
	Cape Town	SEW-EURODRIVE (PROPRIETARY) LIMITED Rainbow Park Cnr. Racecourse & Omuramba Road Montague Gardens Cape Town P.O.Box 36556 Chempet 7442	Tel. +27 21 552-9820 Fax +27 21 552-9830 Telex 576 062 bgriffiths@sew.co.za
	Durban	SEW-EURODRIVE (PROPRIETARY) LIMITED 48 Prospect Road Isipingo Durban P.O. Box 10433, Ashwood 3605	Tel. +27 31 902 3815 Fax +27 31 902 3826 cdejager@sew.co.za
	Nelspruit	SEW-EURODRIVE (PROPRIETARY) LIMITED 7 Christie Crescent Vintonia P.O.Box 1942 Nelspruit 1200	Tel. +27 13 752-8007 Fax +27 13 752-8008 robermeyer@sew.co.za

South Korea

Assembly Sales Service	Ansan	SEW-EURODRIVE KOREA CO., LTD. 7, Dangjaengi-ro, Danwon-gu, Ansan-si, Gyeonggi-do, Zip 425-839	Tel. +82 31 492-8051 Fax +82 31 492-8056 http://www.sew-eurodrive.kr master.korea@sew-eurodrive.com
------------------------------	-------	--	--

South Korea

Busan	SEW-EURODRIVE KOREA CO., LTD. 28, Noksansandan 262-ro 50beon-gil, Gangseo-gu, Busan, Zip 618-820	Tel. +82 51 832-0204 Fax +82 51 832-0230
-------	---	---

Spain

Assembly Sales Service	Bilbao	SEW-EURODRIVE ESPAÑA, S.L. Parque Tecnológico, Edificio, 302 48170 Zamudio (Vizcaya)	Tel. +34 94 43184-70 Fax +34 94 43184-71 http://www.sew-eurodrive.es sew.spain@sew-eurodrive.es
------------------------------	--------	--	--

Sri Lanka

Sales	Colombo	SM International (Pte) Ltd 254, Galle Raod Colombo 4, Sri Lanka	Tel. +94 1 2584887 Fax +94 1 2582981
-------	---------	---	---

Swaziland

Sales	Manzini	C G Trading Co. (Pty) Ltd PO Box 2960 Manzini M200	Tel. +268 2 518 6343 Fax +268 2 518 5033 engineering@cgtrading.co.sz
-------	---------	--	---

Sweden

Assembly Sales Service	Jönköping	SEW-EURODRIVE AB Gnejsvägen 6-8 553 03 Jönköping Box 3100 S-550 03 Jönköping	Tel. +46 36 34 42 00 Fax +46 36 34 42 80 http://www.sew-eurodrive.se jonkoping@sew.se
------------------------------	-----------	---	--

Switzerland

Assembly Sales Service	Basel	Alfred Imhof A.G. Jurastrasse 10 4142 Münchenstein bei Basel	Tel. +41 61 417 1717 Fax +41 61 417 1700 http://www.imhof-sew.ch info@imhof-sew.ch
------------------------------	-------	--	--

Taiwan

Sales	Taipei	Ting Shou Trading Co., Ltd. 6F-3, No. 267, Sec. 2 Tung Huw S. Road Taipei	Tel. +886 2 27383535 Fax +886 2 27368268 Telex 27 245 sewtwn@ms63.hinet.net http://www.tingshou.com.tw
	Nan Tou	Ting Shou Trading Co., Ltd. No. 55 Kung Yeh N. Road Industrial District Nan Tou 540	Tel. +886 49 255353 Fax +886 49 257878 sewtwn@ms63.hinet.net http://www.tingshou.com.tw

Tanzania

Sales	Daressalam	SEW-EURODRIVE PTY LIMITED TANZANIA Plot 52, Regent Estate PO Box 106274 Dar Es Salaam	Tel. +255 0 22 277 5780 Fax +255 0 22 277 5788 http://www.sew-eurodrive.co.tz info@sew.co.tz
-------	------------	--	--

Thailand

Assembly Sales Service	Chonburi	SEW-EURODRIVE (Thailand) Ltd. 700/456, Moo.7, Donhuaroh Muang Chonburi 20000	Tel. +66 38 454281 Fax +66 38 454288 sewthailand@sew-eurodrive.com
------------------------------	----------	---	---

Tunisia

Sales	Tunis	T. M.S. Technic Marketing Service Zone Industrielle Mghira 2 Lot No. 39 2082 Fouchana	Tel. +216 79 40 88 77 Fax +216 79 40 88 66 http://www.tms.com.tn tms@tms.com.tn
-------	-------	--	--

Turkey

Assembly Sales Service	Kocaeli-Gebze	SEW-EURODRIVE Hareket Sistemleri San. Ve TIC. Ltd. Sti Gebze Organize Sanayi Böl. 400 Sok No. 401 41480 Gebze Kocaeli	Tel. +90 262 9991000 04 Fax +90 262 9991009 http://www.sew-eurodrive.com.tr sew@sew-eurodrive.com.tr
------------------------------	---------------	--	---

Ukraine			
Assembly Sales Service	Dnipropetrovsk	ООО «СЕВ-Евродрайв» ул. Рабочая, 23-В, офис 409 49008 Днепропетровск	Tel. +380 56 370 3211 Fax +380 56 372 2078 http://www.sew-eurodrive.ua sew@sew-eurodrive.ua
Uruguay			
Assembly Sales	Montevideo	SEW-EURODRIVE Uruguay, S. A. Jose Serrato 3569 Esquina Corumbe CP 12000 Montevideo	Tel. +598 2 21181-89 Fax +598 2 21181-90 sewuy@sew-eurodrive.com.uy
USA			
Production Assembly Sales Service	Southeast Region	SEW-EURODRIVE INC. 1295 Old Spartanburg Highway P.O. Box 518 Lyman, S.C. 29365	Tel. +1 864 439-7537 Fax Sales +1 864 439-7830 Fax Production +1 864 439-9948 Fax Assembly +1 864 439-0566 Fax Confidential/HR +1 864 949-5557 http://www.seweurodrive.com cslyman@seweurodrive.com
Assembly Sales Service	Northeast Region	SEW-EURODRIVE INC. Pureland Ind. Complex 2107 High Hill Road, P.O. Box 481 Bridgeport, New Jersey 08014	Tel. +1 856 467-2277 Fax +1 856 845-3179 csbridgeport@seweurodrive.com
	Midwest Region	SEW-EURODRIVE INC. 2001 West Main Street Troy, Ohio 45373	Tel. +1 937 335-0036 Fax +1 937 332-0038 cstroy@seweurodrive.com
	Southwest Region	SEW-EURODRIVE INC. 3950 Platinum Way Dallas, Texas 75237	Tel. +1 214 330-4824 Fax +1 214 330-4724 csdallas@seweurodrive.com
	Western Region	SEW-EURODRIVE INC. 30599 San Antonio St. Hayward, CA 94544	Tel. +1 510 487-3560 Fax +1 510 487-6433 cshayward@seweurodrive.com
	Wellford	SEW-EURODRIVE INC. 148/150 Finch Rd. Wellford, S.C. 29385	IGLogistics@seweurodrive.com
Additional addresses for service provided on request!			
Uzbekistan			
Technical Office	Tashkent	SEW-EURODRIVE LLP Representative office in Uzbekistan 96A, Sharaf Rashidov street, Tashkent, 100084	Tel. +998 71 2359411 Fax +998 71 2359412 http://www.sew-eurodrive.uz sew@sew-eurodrive.uz
Vietnam			
Sales	Ho Chi Minh City	Nam Trung Co., Ltd Huế - South Vietnam / Construction Materials 250 Binh Duong Avenue, Thu Dau Mot Town, Binh Duong Province HCM office: 91 Tran Minh Quyen Street District 10, Ho Chi Minh City	Tel. +84 8 8301026 Fax +84 8 8392223 khanh-nguyen@namtrung.com.vn http://www.namtrung.com.vn
	Hanoi	MICO LTD Quảng Trị - North Vietnam / All sectors except Construction Materials 8th Floor, Ocean Park Building, 01 Dao Duy Anh St, Ha Noi, Viet Nam	Tel. +84 4 39386666 Fax +84 4 3938 6888 nam_ph@micogroup.com.vn http://www.micogroup.com.vn

Index

A

Advanced parameter description.....	71
Ambient conditions	98
Assembly	
Safety notes	10

C

Communication socket RJ45.....	31
Conformity	98
Connection	
Safety notes	10
Copyright notice	7

D

Designated use	9
Dimensions.....	16

E

Electrical connection	10
Electrical installation	20
Before installation.....	20
Installation	23
Electromagnetic compatibility	34
Interference emission	34
Interference immunity	34
Operation on TN system with FI switch (IP20)	23
Embedded safety notes.....	6
Error list	63
Exclusion of liability	7
Extended storage	65

F

Factory setting, reset parameter	42
--	----

H

Housing variants.....	16
-----------------------	----

I

Input voltage ranges	12
Installation	15
Frequency inverter and motor	26
IP20 housing	19
Terminal box connections	25
Inverter status.....	62
IT systems	22

K

Keypad	
Parameter setting	41

L

LT Shell	
Parameter setting	45

M

Mechanical installation	16
-------------------------------	----

N

Notes	
Designation in the documentation	6

O

Operation.....	62
On the IT network.....	22
Safety notes	11
Output power with EMC filter.....	104
Output power without EMC filter.....	99
Overload	13
Overview of parameters	67
Overview of signal terminals	29

P

P-15 Digital inputs	90
Parameter.....	67
Parameter setting	
With the keypad.....	41
With the PC (LT Shell software)	45
Product names	7
Protection functions	14
Protective separation.....	10

R

Register allocation	55
Repair	65
Residual current device	21
Rights to claim under limited warranty	7
RJ45 communication socket	31

S

Safety notes	
General.....	8

Assembly	10
Designation in the documentation	6
Preliminary information	8
Structure of embedded	6
Structure of the section-related	6
Section-related safety notes	6
Separation, protective	10
Service	65
Error codes	63
SEW-EURODRIVE Electronics Service	65
Signal words in the safety notes	6
Simple startup	42
Specifications	12
Startup	40


Operator terminal control	43
Safety notes	11
Terminal control	42

T

Target group	9
Technical data	98
Trademarks	7
Transportation	10
Type designation	13

U

Use	9
User interface	40
Keypad	40







SEW-EURODRIVE
Driving the world

SEW
EURODRIVE

SEW-EURODRIVE GmbH & Co KG
P.O. Box 3023
76642 BRUCHSAL
GERMANY
Phone +49 7251 75-0
Fax +49 7251 75-1970
sew@sew-eurodrive.com
→ www.sew-eurodrive.com